




PARTS CATALOGUE

F200/F200A'06 (60L5)

F225/F225A'06 (69J5)

LF200/FL200A'06 (60M5)

LF225/FL225A'06 (69K5)



1E60L-100E1

(2E60L-100E1)

2005/12/19

NEWS NO.	DATE	COMMENT
PE0-OM-050013	September,20,2005	MOD:FIG.32,34 PINION & GEAR P/No. REVISION

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

“UR” Use specified parts number.

“UN” Use as many as needed.

“AP” Alternate Parts

“LM” Locally Made (Parts need to be ordered locally)

“F#” Frame No. (Applicable machine No.)

“O/S” Over Size

3. The number of components for assembly

- Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
- The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5-83310-60	FRONT FLASHER LIGHT ASSY	2	
115-83311-60	.BULB (6V-18W)	1	

4. Applicable colours of graphics are represented in the “REMARKS” as shown below.


PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4-24110-00-X5	FUEL TANK COMP.	2	MXR
3J1-24240-10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.

6. The asterisk (*) before a reference number indicates modified items after the first edition.

7. Applicable Serial No.

Engine Serial No.



8. Applicable Engine Starting Serial No.

Model	Serial No.	Model	Serial No.
F200	60L-1005828	F200A	60L-1005828
F225	69J-1021983	F225A	69J-1021983
LF200	60M-1000986	FL200A	60M-1000986
LF225	69K-1006907	FL225A	69K-1006907

9. Applicable Colour Code

Abbreviation	Colour Name	Colour Code
DBN1	DARK BLUISH GRAY 1	008D

10. Quantity Column Information

Column No.	Name Of Q'ty Column	Applicable Model
1	69J5	F225TR, F225AET
2	60L5	F200TR, F200AET
3	69K5	LF225TR, FL225AET
4	60M5	LF200TR, FL200AET

CONTENTS

SHEET1/2

TOP COWLING	A4
CYLINDER & CRANKCASE 1	A6
CRANKSHAFT & PISTON	B2
CYLINDER & CRANKCASE 2	B3
CYLINDER & CRANKCASE 3	B5
VALVE	B6
INTAKE 1	C2
INTAKE 2	C4
THROTTLE BODY ASSY 1	C5
THROTTLE BODY ASSY 2	C7
THROTTLE BODY ASSY 3	D2
FUEL INJECTION PUMP 1	D4
FUEL INJECTION PUMP 2	D6
FUEL 1	D7
FUEL 2	E1
GENERATOR	E2
ELECTRICAL 1	E4
ELECTRICAL 2	E6
ELECTRICAL 3	F1
STARTING MOTOR	F2
BOTTOM COWLING 1	F4
BOTTOM COWLING 2	F7

INDEX

NUMERICAL INDEX	G1
-----------------------	----

SHEET2/2

CONTROL 1	A4*
CONTROL 2	A6*
CONTROL 3	B1*
BRACKET 1	B2*
BRACKET 2	B4*
POWER TRIM & TILT ASSY 1	B6*
POWER TRIM & TILT ASSY 2	C2*
UPPER CASING	C3*
OIL PAN	C6*
LOWER CASING & DRIVE 1	C7*
LOWER CASING & DRIVE 2	D4*
LOWER CASING & DRIVE 3	D6*
LOWER CASING & DRIVE 4	E3*
STEERING GUIDE	E5*
REMOTE CONTROL BOX	E6*
METER	E7*
SWITCH & PANEL 1	F2*
SWITCH & PANEL 2	F3*
SWITCH & PANEL 3	F4*
REPAIR KIT 1	F5*
REPAIR KIT 2	F6*

INDEX

NUMERICAL INDEX	G1*
-----------------------	-----




FIG. 1 TOP COWLING

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-42610-01-8D	TOP COWLING ASSY	1		1		
	60L-42610-01-8D	TOP COWLING ASSY		1		1	
2	69J-42613-00	.MOLDING, AIR DUCT	1	1	1	1	
3	90179-06M28	.NUT	9	9	9	9	
4	68F-42647-01-94	.HOLDER, CLAMP BAND	1	1	1	1	
5	69J-42647-00-94	.HOLDER, CLAMP BAND	1	1	1	1	
6	69J-42663-00	.DAMPER	1	1	1	1	
7	92990-06100	.WASHER, SPRING	6	6	6	6	
8	95380-06600	.NUT, HEXAGON	6	6	6	6	
9	68F-42651-00	.HOOK	2	2	2	2	
10	97095-06016	.BOLT	6	6	6	6	
11	92995-06600	.WASHER	6	6	6	6	
12	68F-42663-00	.DAMPER	2	2	2	2	
13	68F-42648-01-94	.HOLDER, CLAMP BAND	1	1	1	1	
14	67F-42652-00	.HOOK	1	1	1	1	
15	67F-13448-00	.CAP	3	3	3	3	
16	69J-42678-00	.GRAPHIC, REAR	1		1		
	60L-42678-00	.GRAPHIC, REAR		1		1	
17	69J-W0070-00	.GRAPHIC SET	1	1	1	1	
18	69J-42677-00	.GRAPHIC, FRONT	1		1		
	60L-42677-00	.GRAPHIC, FRONT		1		1	
19	69J-42681-00	.MARK, COWLING	1	1	1	1	
20	69J-42682-00	.MARK, COWLING	1	1	1	1	
21	69J-24378-00	.PIPE, JOINT 4	1	1	1	1	
22	90445-11020	.HOSE (L400)	2	2	2	2	
23	90445-11021	.HOSE (L310)	1	1	1	1	
24	69J-42617-00	.DAMPER, FORM	1	1	1	1	




FIG. 1 TOP COWLING

[illegible]




FIG. 2 CYLINDER & CRANKCASE 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-W009B-04-1S	CYLINDER BLOCK ASSY	1	1	1	1	
2	69J-15100-11-1S	CRANKCASE ASSY	1	1	1	1	
3	93606-12019	.PIN, DOWEL	1	1	1	1	
4	91814-18001	.PIN, DOWEL	8	8	8	8	
5	69J-15123-00	PLATE, BUFFLE 1	1	1	1	1	
6	69J-15187-00	BOLT	8	8	8	8	
7	69J-15481-00	BOLT 1	2	2	2	2	
8	69J-15482-00	BOLT 2	6	6	6	6	
9	95707-06500	NUT, FLANGE	6	6	6	6	
10	90119-08M66	BOLT, WITH WASHER	13	13	13	13	
11	69J-15411-00-94	COVER, CRANKCASE 1	1	1	1	1	
12	69J-15451-00	GASKET, CRANKCASE COVER 1	1	1	1	1	
13	93606-12019	PIN, DOWEL	2	2	2	2	
14	90119-08009	BOLT, WITH WASHER	17	17	17	17	
15	69J-11168-00	COVER, BREATHER	1	1	1	1	
16	98507-04008	SCREW, PAN HEAD	14	14	14	14	
17	92907-04600	WASHER	14	14	14	14	
18	69J-11119-00	HANGER, ENGINE	1	1	1	1	
19	90119-06MA2	BOLT, WITH WASHER	2	2	2	2	
20	69J-1131C-01-1S	COVER, JOINT	1	1	1	1	
21	6S1-1131B-00	GASKET, COVER	1	1	1	1	
22	90119-06MA4	BOLT, WITH WASHER	13	13	13	13	
23	67F-12411-01	THERMOSTAT	2	2	2	2	
24	6P2-1240H-00-1S	ANODE ASSY	1	1	1	1	
25	90109-06M80	.BOLT	2	2	2	2	
26	6P3-11325-00	.ANODE	1	1	1	1	
27	90105-05012	.BOLT, FLANGE	1	1	1	1	




FIG. 2 CYLINDER & CRANKCASE 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
28	90430-05002	.GASKET	1	1	1	1	
29	6P3-1240H-00-1S	ANODE ASSY	1	1	1	1	
30	90109-06M80	.BOLT	2	2	2	2	
31	6P3-11325-00	.ANODE	1	1	1	1	
32	90105-05012	.BOLT, FLANGE	1	1	1	1	
33	90430-05002	.GASKET	1	1	1	1	
34	90340-14M06	PLUG, STRAIGHT SCREW	1	1	1	1	
35	90430-14115	GASKET	1	1	1	1	
36	97095-06025	BOLT	4	4	4	4	
37	92995-06600	WASHER	4	4	4	4	
38	69J-1243A-00	HOSE 1	1	1	1	1	
39	69J-1243E-00	HOSE 2	1	1	1	1	
40	90465-11M10	CLAMP	4	4	4	4	
41	69J-11351-11	GASKET, CYLINDER	1	1	1	1	
42	67F-42761-00-94	STOPPER	2	2	2	2	
43	68F-44533-00	DAMPER, UPPER MOUNT RUBBER	2	2	2	2	
44	97095-06025	BOLT	4	4	4	4	
45	92995-06600	WASHER	4	4	4	4	
46	93210-25552	O-RING	1	1	1	1	
47	93210-19MJ1	O-RING	2	2	2	2	
48	69J-11313-00-94	PLUG, BLIND	1	1	1	1	
49	93210-25647	O-RING	1	1	1	1	
50	97095-06020	BOLT	2	2	2	2	
51	92995-06600	WASHER	2	2	2	2	
52	69J-14664-00	GROMMET, WATER SHUT	2	2	2	2	
53	69J-13440-00	ELEMENT ASSY, OIL CLEANER	1	1	1	1	
54	69J-12858-00	BOLT, UNION	1	1	1	1	





FIG. 2 CYLINDER & CRANKCASE 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
55	69J-13446-00-94	CONNECTOR	1	1	1	1	
56	69J-13477-00	GASKET	1	1	1	1	
57	97095-06045	BOLT	3	3	3	3	
58	92995-06600	WASHER	3	3	3	3	
59	69J-13447-00	COVER, OIL ELEMENT	1	1	1	1	
60	97095-06040	BOLT	1	1	1	1	
61	92995-06600	WASHER	1	1	1	1	
62	6G8-15363-00	PLUG, OIL	1	1	1	1	
63	93210-24M79	O-RING	1	1	1	1	
64	69J-15319-00-1S	JOINT	1	1	1	1	
65	69J-15364-A0	GASKET, OIL PLUG	1	1	1	1	
66	97095-06045	BOLT	2	2	2	2	
67	92995-06600	WASHER	2	2	2	2	
68	69J-82560-00	THERMO SWITCH ASSY	2	2	2	2	
69	90465-11M10	CLAMP	2	2	2	2	
70	6E9-82588-00	PLATE	2	2	2	2	
71	69J-83651-00	SENDER, OIL PRESSURE	1	1	1	1	
72	6E5-11325-00	ANODE	4	4	4	4	
73	98780-04015	SCREW, FLAT HEAD	4	4	4	4	



69J1010-2030

FIG. 3 CRANKSHAFT & PISTON

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-11411-00	CRANKSHAFT	1	1	1	1	
2	93102-63004	OIL SEAL	1	1	1	1	
3	69J-11416-00	PLANE BEARING, CRANKSHAFT 1	4	4	4	4	UR #1
	69J-11416-10	PLANE BEARING, CRANKSHAFT 1	4	4	4	4	UR #2
	69J-11416-20	PLANE BEARING, CRANKSHAFT 1	4	4	4	4	UR #3
4	69J-11417-00	PLANE BEARING, CRANKSHAFT 2	3	3	3	3	UR #1
	69J-11417-10	PLANE BEARING, CRANKSHAFT 2	3	3	3	3	UR #2
	69J-11417-20	PLANE BEARING, CRANKSHAFT 2	3	3	3	3	UR #3
5	69J-11426-00	PLANE BEARING, CRANKSHAFT 1	1	1	1	1	UR #1
	69J-11426-10	PLANE BEARING, CRANKSHAFT 1	1	1	1	1	UR #2
	69J-11426-20	PLANE BEARING, CRANKSHAFT 1	1	1	1	1	UR #3
6	69J-11427-00	PLANE BEARING, CRANKSHAFT 2	2	2	2	2	
7	69J-W1165-01	CONNECTING ROD ASSY	6	6	6	6	
8	69J-11654-00	.BOLT, CONNECTING ROD	2	2	2	2	
9	69J-11656-00	PLANE BEARING, CONNECTING ROD	12	12	12	12	UR YELLOW
	69J-11656-10	PLANE BEARING, CONNECTING ROD	12	12	12	12	UR GREEN
	69J-11656-20	PLANE BEARING, CONNECTING ROD	12	12	12	12	UR BLUE
10	69J-11631-02-B0	PISTON (STD)	6	6	6	6	
	69J-11635-00	PISTON (0.25MM O/S)	6	6	6	6	AP
11	63P-11603-01	PISTON RING SET (STD)	6	6	6	6	
	63P-11604-00	PISTON RING SET (0.25MM O/S)	6	6	6	6	AP
12	69J-11633-00	PIN, PISTON	6	6	6	6	
13	69J-11634-00	CLIP, PISTON PIN	12	12	12	12	




FIG. 4 CYLINDER & CRANKCASE 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-W009A-04-1S	CYLINDER HEAD ASSY	1	1	1	1	
2	69J-11110-01-94	CYLINDER HEAD ASSY	1	1	1	1	
3	69J-11133-10	.GUIDE, VALVE 1	12	12	12	12	
4	90344-51019	.PLUG, TAPER SCREW	5	5	5	5	
5	91809-08006	.SLEEVE GUIDE-DOWEL	2	2	2	2	
6	90119-07235	.BOLT/WASHER-CAM CAPS	2	2	2	2	
7	90119-07234	.BOLT, WITH WASHER	18	18	18	18	
8	69J-W009C-04-1S	CYLINDER HEAD ASSY 2	1	1	1	1	
9	69J-11120-01-94	CYLINDER HEAD ASSY 2	1	1	1	1	
10	69J-11133-10	.GUIDE, VALVE 1	12	12	12	12	
11	90344-51019	.PLUG, TAPER SCREW	5	5	5	5	
12	91809-08006	.SLEEVE GUIDE-DOWEL	2	2	2	2	
13	90119-07235	.BOLT/WASHER-CAM CAPS	2	2	2	2	
14	90119-07234	.BOLT, WITH WASHER	14	14	14	14	
15	68V-11325-01	ANODE	4	4	4	4	
16	69J-11327-00-94	COVER, ANODE	4	4	4	4	
17	97075-06020	BOLT	4	4	4	4	
18	92995-06600	WASHER	4	4	4	4	
19	67F-11328-00	GROMMET, ANODE	4	4	4	4	
20	97575-08540	BOLT, WITH WASHER	4	4	4	4	
21	69J-11181-03	GASKET, CYLINDER HEAD 1	1	1	1	1	
22	90387-10M08	COLLAR	2	2	2	2	
23	90155-10001	SCREW, FLAT FILLISTER	8	8	8	8	
24	90119-08M91	BOLT, WITH WASHER	2	2	2	2	
25	90119-08021	BOLT, WITH WASHER	1	1	1	1	
26	69J-11182-03	GASKET, CYLINDER HEAD 2	1	1	1	1	
27	90387-10M08	COLLAR	2	2	2	2	





FIG. 4 CYLINDER & CRANKCASE 2

[illegible]



69J5100-E050

FIG. 5 CYLINDER & CRANKCASE 3

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-41111-01-1S	INNER COVER, EXHAUST	1	1	1	1	
2	69J-41121-01-1S	INNER COVER, EXHAUST	1	1	1	1	
3	69J-41113-01-1S	OUTER COVER, EXHAUST	1	1	1	1	
4	69J-41123-01-1S	OUTER COVER, EXHAUST	1	1	1	1	
5	6P2-41112-00	GASKET, EXHAUST INNER COVER	1	1	1	1	
6	6P2-41122-00	GASKET, EXHAUST INNER COVER	1	1	1	1	
7	6P2-41114-00	GASKET, EXHAUST OUTER COVER	2	2	2	2	
8	6P2-11325-00	ANODE	2	2	2	2	
9	6E5-11325-00	ANODE	2	2	2	2	
10	98780-04015	SCREW, FLAT HEAD	2	2	2	2	
11	90151-06M02	SCREW, COUNTERSUNK	2	2	2	2	
12	91690-40010	PIN, SPRING	2	2	2	2	
13	90119-06027	BOLT, WITH WASHER	26	26	26	26	
14	90119-06104	BOLT, WITH WASHER	2	2	2	2	
15	97095-08014	BOLT	4	4	4	4	
16	90430-08143	GASKET	4	4	4	4	
17	90340-18M09	PLUG, STRAIGHT SCREW	2	2	2	2	
18	90430-18130	GASKET	2	2	2	2	
19	6P2-11119-00	HANGER, ENGINE	2	2	2	2	
20	90119-06MA2	BOLT, WITH WASHER	4	4	4	4	
21	69J-11111M-00	COVER 1	1	1	1	1	
22	90340-14M06	PLUG, STRAIGHT SCREW	1	1	1	1	
23	90430-14115	GASKET	1	1	1	1	
24	69J-2134V-00	BRACKET	1	1	1	1	




FIG. 6 VALVE

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-12111-00	VALVE, INTAKE	12	12	12	12	
2	69J-12121-00	VALVE, EXHAUST	12	12	12	12	
3	69J-12113-01	SPRING, VALVE INNER	24	24	24	24	
4	69J-12117-01	RETAINER, VALVE SPRING	24	24	24	24	
5	69J-12118-00	COTTER, VALVE	48	48	48	48	
6	69J-12119-00	SEAL, VALVE STEM	24	24	24	24	
7	69J-12153-00	LIFTER, VALVE	24	24	24	24	
8	69J-12168-00	PAD, ADJUSTING (2.320)	24	24	24	24	UR
	69J-12168-10	PAD, ADJUSTING (2.340)	24	24	24	24	UR
	69J-12168-20	PAD, ADJUSTING (2.360)	24	24	24	24	UR
	69J-12168-30	PAD, ADJUSTING (2.380)	24	24	24	24	UR
	69J-12168-40	PAD, ADJUSTING (2.400)	24	24	24	24	UR
	69J-12168-50	PAD, ADJUSTING (2.420)	24	24	24	24	UR
	69J-12168-60	PAD, ADJUSTING (2.440)	24	24	24	24	UR
	69J-12168-70	PAD, ADJUSTING (2.460)	24	24	24	24	UR
	69J-12168-80	PAD, ADJUSTING (2.480)	24	24	24	24	UR
	69J-12168-90	PAD, ADJUSTING (2.500)	24	24	24	24	UR
	69J-12168-A0	PAD, ADJUSTING (2.520)	24	24	24	24	UR
	69J-12168-B0	PAD, ADJUSTING (2.540)	24	24	24	24	UR
	69J-12168-C0	PAD, ADJUSTING (2.560)	24	24	24	24	UR
	69J-12168-D0	PAD, ADJUSTING (2.580)	24	24	24	24	UR
	69J-12168-E0	PAD, ADJUSTING (2.600)	24	24	24	24	UR
	69J-12168-F0	PAD, ADJUSTING (2.620)	24	24	24	24	UR
	69J-12168-G0	PAD, ADJUSTING (2.640)	24	24	24	24	UR
	69J-12168-H0	PAD, ADJUSTING (2.660)	24	24	24	24	UR
	69J-12168-J0	PAD, ADJUSTING (2.680)	24	24	24	24	UR
	69J-12168-K0	PAD, ADJUSTING (2.700)	24	24	24	24	UR




FIG. 6 VALVE

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
8	69J-12168-L0	PAD, ADJUSTING (2.720)	24	24	24	24	UR
	69J-12168-M0	PAD, ADJUSTING (2.740)	24	24	24	24	UR
	69J-12168-N0	PAD, ADJUSTING (2.760)	24	24	24	24	UR
	69J-12168-P0	PAD, ADJUSTING (2.780)	24	24	24	24	UR
	69J-12168-R0	PAD, ADJUSTING (2.800)	24	24	24	24	UR
---	69J-12168-S0	PAD, ADJUSTING (2.820)	24	24	24	24	UR
	69J-12168-T0	PAD, ADJUSTING (2.840)	24	24	24	24	UR
	69J-12168-U0	PAD, ADJUSTING (2.860)	24	24	24	24	UR
	69J-12168-V0	PAD, ADJUSTING (2.880)	24	24	24	24	UR
	69J-12168-W0	PAD, ADJUSTING (2.900)	24	24	24	24	UR
---	69J-12168-X0	PAD, ADJUSTING (2.920)	24	24	24	24	UR
	69J-12168-Y0	PAD, ADJUSTING (2.940)	24	24	24	24	UR
	69J-12169-00	PAD, ADJUSTING (2.960)	24	24	24	24	UR
9	69J-12171-00	CAMSHAFT 1	1	1	1	1	
10	69J-12181-00	CAMSHAFT 2	1	1	1	1	
11	69J-12172-00	CAMSHAFT 3	1	1	1	1	
12	69J-12182-00	CAMSHAFT 4	1	1	1	1	
13	94581-99044	CHAIN	2	2	2	2	
14	69J-12210-00	TENSIONER ASSY, CAM CHAIN	1	1	1	1	
15	69J-12230-00	TENSIONER ASSY, CAM CHAIN 2	1	1	1	1	
16	97013-06025	BOLT	4	4	4	4	
17	93605-10108	PIN, DOWEL	2	2	2	2	
18	69J-11537-00	GEAR, DRIVEN	2	2	2	2	
19	90119-10M06	BOLT, WITH WASHER	2	2	2	2	
20	93102-38M59	OIL SEAL	2	2	2	2	
21	69J-46241-00	V-BELT	1	1	1	1	
22	63P-11590-00	TENSIONER ASSY	1	1	1	1	




FIG. 6 VALVE

[illegible]




FIG. 7 INTAKE 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-14146-11	PLATE	1	1	1	1	
2	69J-14162-00	BOLT, HOLDING	1	1	1	1	
3	68V-24519-00	CLIP	1	1	1	1	
4	90116-06032	BOLT, STUD	4	4	4	4	
5	90465-14M66	CLAMP	1	1	1	1	
6	69J-1442A-00	COVER, CLEANER CASE 3	1	1	1	1	
7	69J-14409-00	DAMPER	1	1	1	1	
8	97780-60620	SCREW, TAPPING	3	3	3	3	
9	69J-12483-00	PIPE 3	1	1	1	1	
10	90467-09M03	CLIP	2	2	2	2	
11	69J-13645-00	GASKET, MANIFOLD 1	2	2	2	2	
12	90119-08022	BOLT, WITH WASHER	18	18	18	18	
13	91690-50014	PIN, SPRING	4	4	4	4	
14	90101-06M75	BOLT	4	4	4	4	
15	90201-06068	WASHER, PLATE	4	4	4	4	
16	69J-14440-00	SILENCER ASSY, INTAKE	1	1	1	1	
17	90387-07005	.COLLAR	2	2	2	2	
18	69J-1444F-00	SILENCER ASSY, INTAKE 2	1	1	1	1	
19	90387-07005	.COLLAR	2	2	2	2	
20	69J-14419-00	PIPE	2	2	2	2	
21	90465-11M52	CLAMP	4	4	4	4	
22	69J-14457-00	SEAL	6	6	6	6	
23	90386-08001	BUSH	8	8	8	8	
24	90119-06036	BOLT, WITH WASHER	4	4	4	4	
25	90387-06038	COLLAR	4	4	4	4	
26	90179-06M28	NUT	4	4	4	4	
27	69J-15373-00	PIPE, BREATHER	1	1	1	1	




FIG. 7 INTAKE 1

[illegible]




FIG. 8 INTAKE 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	60L-24315-01	PIPE 5	1	1	1	1	
2	90464-12238	CLAMP	2	2	2	2	
3	90464-23001	CLAMP	1	1	1	1	
4	69J-24170-00	CANISTER ASSY	1	1	1	1	
5	69J-2134X-00	BRACKET, CANISTER	1	1	1	1	
6	90480-10M23	GROMMET	2	2	2	2	
7	90387-06M60	COLLAR	2	2	2	2	
8	90119-06M59	BOLT, WITH WASHER	2	2	2	2	
9	69J-2419A-00	HOLDER	1	1	1	1	
10	97095-06016	BOLT	1	1	1	1	
11	92995-06600	WASHER	1	1	1	1	
12	6E5-24379-00	PIPE, JOINT 4	2	2	2	2	
13	60L-24314-01	PIPE 4	1	1	1	1	
14	60L-24313-00	PIPE 3	1	1	1	1	
15	90448-12003	HOSE, WITH UNION	1	1	1	1	
16	69J-24502-00	FILTER, FUEL	1	1	1	1	
17	60L-24312-00	PIPE 2	1	1	1	1	
18	90448-12001	HOSE, WITH UNION	1	1	1	1	
19	60L-24311-00	PIPE, FUEL 1	1	1	1	1	
20	90448-10002	HOSE, WITH UNION	1	1	1	1	
21	60L-24367-00	CLAMP, FUEL PIPE 2	1	1	1	1	
22	60L-24366-00	CLAMP, FUEL PIPE 1	1	1	1	1	
23	90465-11M10	CLAMP	11	11	11	11	




FIG. 9 THROTTLE BODY ASSY 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-13750-01	THROTTLE BODY ASSY	1		1		
	60L-13750-01	THROTTLE BODY ASSY		1		1	
2	69J-13751-01	.BODY, THROTTLE 1	1		1		
	60L-13751-01	.BODY, THROTTLE 1		1		1	
3	3CF-14594-00	..NUT	1	1	1	1	
4	92990-08100	..WASHER, SPRING	1	1	1	1	
5	68V-14323-00	..SCREW, AIR ADJUSTING	1	1	1	1	
6	68V-14331-00	..SPRING, THROTTLE VALVE	1	1	1	1	
7	69J-13753-01	.BODY, THROTTLE 3	1		1		
	60L-13753-01	.BODY, THROTTLE 3			1	1	
8	3CF-14594-00	..NUT	1	1	1	1	
9	92990-08100	..WASHER, SPRING	1	1	1	1	
10	69J-13755-01	.BODY, THROTTLE 5	1		1		
	60L-13755-01	.BODY, THROTTLE 5			1	1	
11	3CF-14594-00	..NUT	1	1	1	1	
12	92990-08100	..WASHER, SPRING	1	1	1	1	
13	69J-13576-00	.SPACER	1	1	1	1	
14	68V-81145-01	.SCREW 1	2	2	2	2	
15	68V-14565-00	.SCREW	2	2	2	2	
16	68V-14331-00	.SPRING, THROTTLE VALVE	4	4	4	4	
17	69J-14261-00	..HOLDER	1	1	1	1	
18	6S1-85885-00	.THROTTLE SENSOR ASSY	1	1	1	1	
19	69J-13160-00	.DELIVERY PIPE ASSY 1	1	1	1	1	
20	69J-14261-00	..HOLDER	1	1	1	1	
21	69J-14295-00	..PIPE, FUEL	1	1	1	1	
22	69J-14251-00	..NIPPLE	1	1	1	1	
23	68V-14397-00	..O-RING	2	2	2	2	




FIG. 9 THROTTLE BODY ASSY 1

REF. NO.	PART NO.	DESCRIPTION	68J5	60L5	69K5	60M5	REMARKS
24	68V-81147-00	..SCREW 3	4	4	4	4	
25	69J-13641-00	.MANIFOLD 1	1	1	1	1	
26	97095-06010	.BOLT	3	3	3	3	
27	90430-06014	.GASKET	3	3	3	3	
28	69J-13557-00	.GASKET	3	3	3	3	
29	99530-10114	.PIN, DOWEL	6	6	6	6	
30	69J-14496-00	.BOLT	6	6	6	6	
31	68V-14475-00	.WASHER	9	9	9	9	
32	69J-13761-00	.INJECTOR ASSY	3	3	3	3	
33	68V-1410B-00	..PACKING KIT	1	1	1	1	
34	68V-13766-00	.RUBBER, INJECTOR	3	3	3	3	
35	68V-14264-00	.COLLAR	3	3	3	3	
36	68V-14428-00	.BOLT	3	3	3	3	
37	69J-14321-00	.SCREW, THROTTLE	2	2	2	2	
38	69J-13973-00	.PIPE, FUEL 3	1	1	1	1	
39	68F-24300-00	.FUEL PIPE JOINT	1	1	1	1	
40	69J-13972-00	.PIPE, FUEL 2	1	1	1	1	
41	69J-24381-00	.SET BAR, FUEL JOINT	1	1	1	1	
42	68V-24387-00	.CLIP	2	2	2	2	
43	69J-14286-00	.SPRING	1		1		
	60L-14286-00	.SPRING		1		1	
44	68V-8182L-00	.O-RING 1	1	1	1	1	
45	69J-14149-00	.PIPE	1	1	1	1	
46	68V-13577-00	.CLIP	2	2	2	2	




FIG. 10 THROTTLE BODY ASSY 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-1375A-11	THROTTLE BODY ASSY 2	1		1		
	60L-1375A-11	THROTTLE BODY ASSY 2		1		1	
2	69J-13752-00	BODY, THROTTLE 2	1		1		
	60L-13752-00	BODY, THROTTLE 2		1		1	
3	3CF-14594-00	.NUT	2	2	2	2	
4	92990-08100	.WASHER, SPRING	2	2	2	2	
5	68V-14323-00	.SCREW, AIR ADJUSTING	1	1	1	1	
6	68V-14331-00	.SPRING, THROTTLE VALVE	1	1	1	1	
7	69J-13754-00	BODY, THROTTLE 4	1		1		
	60L-13754-00	BODY, THROTTLE 4		1		1	
8	3CF-14594-00	.NUT	1	1	1	1	
9	92990-08100	.WASHER, SPRING	1	1	1	1	
10	69J-13756-00	BODY, THROTTLE 6	1		1		
	60L-13756-00	BODY, THROTTLE 6		1		1	
11	3CF-14594-00	.NUT	1	1	1	1	
12	92990-08100	.WASHER, SPRING	1	1	1	1	
13	68V-14331-00	SPRING, THROTTLE VALVE	4	4	4	4	
14	68V-81147-00	SCREW 3	2	2	2	2	
15	69J-14960-00	BODY ASSY	1	1	1	1	
16	68V-13473-00	O-RING	1	1	1	1	
17	68V-1312A-00	VALVE, CONTROL	1	1	1	1	
18	68V-81146-01	SCREW 2	3	3	3	3	
19	68V-82380-00	SENSOR, PRESSURE	1	1	1	1	
20	69J-13642-00	MANIFOLD 2	1	1	1	1	
21	97095-06010	BOLT	3	3	3	3	
22	90430-06014	GASKET	3	3	3	3	
23	69J-13557-00	GASKET	3	3	3	3	




FIG. 10 THROTTLE BODY ASSY 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
24	99530-10114	PIN, DOWEL	6	6	6	6	
25	69J-14496-00	BOLT	6	6	6	6	
26	68V-14475-00	WASHER	6	6	6	6	
27	69J-13761-00	INJECTOR ASSY	3	3	3	3	
28	68V-1410B-00	.PACKING KIT	1	1	1	1	
29	68V-13766-00	RUBBER, INJECTOR	3	3	3	3	
30	69J-14321-00	SCREW, THROTTLE	2	2	2	2	
31	69J-13573-00	BOLT 1	2	2	2	2	
32	69J-13574-00	BOLT 2	1	1	1	1	
33	69J-13547-00	HOSE 3	1	1	1	1	
34	69J-14159-00	CLIP	1	1	1	1	
35	69J-14255-00	PLATE	1	1	1	1	




FIG. 11 THROTTLE BODY ASSY 3

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-13170-00	DELIVERY PIPE ASSY 2	1	1	1	1	
2	69J-13435-00	.NIPPLE	1	1	1	1	
3	68V-14397-00	.O-RING	1	1	1	1	
4	68V-81147-00	.SCREW 3	2	2	2	2	
5	68V-14225-00	.CAP	1	1	1	1	
6	69J-13906-00	.REGULATOR, PRESSURE	1	1	1	1	
7	68V-14565-00	.SCREW	2	2	2	2	
8	68V-14356-00	.WASHER, SPRING	2	2	2	2	
9	68V-14475-00	WASHER	3	3	3	3	
10	68V-14264-00	COLLAR	3	3	3	3	
11	68V-14428-00	BOLT	3	3	3	3	
12	68F-24300-00	FUEL PIPE JOINT	1	1	1	1	
13	68V-24387-00	CLIP	1	1	1	1	
14	69J-13546-00	HOSE 2	1	1	1	1	
15	60L-24317-00	PIPE 7	1	1	1	1	
16	69J-13974-00	PIPE, FUEL 4	1	1	1	1	
17	68V-13544-00	HOSE, VACUUM SENSING 2	1	1	1	1	
18	5JW-14349-00	PIPE	2	2	2	2	
19	69J-13542-00	HOSE, VACUUM SENSING 1	1	1	1	1	
20	69J-13532-00	HOSE, VACUUM SENSING 3	1	1	1	1	
21	69J-13533-00	HOSE, VACUUM SENSING 4	1	1	1	1	
22	68V-24377-00	PIPE, JOINT 3	1	1	1	1	
23	69J-13595-00	JOINT	1	1	1	1	
24	69J-14139-00	CLIP, PIPE	1	1	1	1	
25	69J-13975-00	PIPE, FUEL 5	1	1	1	1	
26	68V-24519-00	CLIP	1	1	1	1	
27	69J-8259L-00	WIRE HARNESS ASSY 1	1	1	1	1	

[illegible]




FIG. 12 FUEL INJECTION PUMP 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-14180-21	FLOAT CHAMBER ASSY	1	1	1	1	
2	69J-14182-10	COVER, FLOAT CHAMBER	1	1	1	1	
3	69J-2411R-00	.PLATE 1	1	1	1	1	
4	69J-2411T-00	.PLATE 2	1	1	1	1	
5	4SV-24453-00	.SCREW	2	2	2	2	
6	69J-14181-00	BODY, FLOAT CHAMBER 1	1	1	1	1	
7	266-14191-00	.PLUG, DRAIN	1	1	1	1	
8	59V-14962-00	.WASHER	1	1	1	1	
9	69J-14985-00	FLOAT	1	1	1	1	
10	68V-14386-00	PIN, FLOAT	1	1	1	1	
11	69J-14546-00	VALVE, NEEDLE	1	1	1	1	
12	68V-13769-00	.O-RING	1	1	1	1	
13	68V-14255-00	PLATE	1	1	1	1	
14	98507-04008	SCREW, PAN HEAD	1	1	1	1	
15	68V-14357-00	WASHER, PLAIN	2	2	2	2	
16	68V-13781-10	DAMPER, PUMP	1	1	1	1	
17	69J-13907-02	FUEL PUMP COMP.	1	1	1	1	
18	68V-13915-00	FILTER	1	1	1	1	
19	68V-13784-00	COVER, PUMP	1	1	1	1	
20	68V-14567-00	SCREW	7	7	7	7	
21	68V-14984-00	GASKET, FLOAT CHAMBER	1	1	1	1	
22	69J-24379-00	PIPE, JOINT 4	1	1	1	1	
23	69J-14148-00	PIPE	2	2	2	2	
24	69J-14197-00	PIPE	1	1	1	1	
25	69J-14989-00	ORIFICE, AIR VENT	1	1	1	1	
26	69J-24410-01	FUEL PUMP ASSY	1	1	1	1	
27	69J-24491-00	BRACKET, FUEL PUMP	1	1	1	1	




FIG. 12 FUEL INJECTION PUMP 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
28	69J-24492-00	BUSH, FUEL PUMP	2	2	2	2	
29	69J-24592-00	BOLT	2	2	2	2	
30	69J-24422-10	PLATE	1	1	1	1	
31	69J-14164-00	NUT, HOLDING	2	2	2	2	
32	69J-21841-01	COOLER	1	1	1	1	
33	68V-14265-00	COLLAR	2	2	2	2	
34	69J-14446-00	BOLT	3	3	3	3	
35	69J-13593-00	DAMPER	4	4	4	4	
36	69J-13716-00	COLLAR	8	8	8	8	
37	69J-14225-00	CAP	1	1	1	1	
38	60L-24321-00	PIPE 10	1	1	1	1	
39	60L-24379-00	PIPE, JOINT 4	1	1	1	1	
40	60L-13490-00	RELIEF VALVE ASSY	1	1	1	1	
41	60L-24316-00	PIPE 6	1	1	1	1	
42	60L-24327-00	PROTECTOR, PIPE	1	1	1	1	
43	69J-2481H-00	CLAMP	1	1	1	1	
44	69J-2481H-10	CLAMP	1	1	1	1	




FIG. 13 FUEL INJECTION PUMP 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-24460-00	RELIEF VALVE ASSY	1	1	1	1	
2	69J-24324-30	PIPE 13	1	1	1	1	
3	69J-24322-10	PIPE 11	1	1	1	1	
4	69J-24323-00	PIPE 12	1	1	1	1	
5	69J-24317-00	PIPE 7	1	1	1	1	
6	69J-24316-00	PIPE 6	1	1	1	1	
7	68V-13577-00	CLIP	6	6	6	6	
8	68V-24519-00	CLIP	6	6	6	6	
9	69J-14137-00	CLIP	4	4	4	4	
10	68V-2481H-00	CLAMP	4	4	4	4	
11	6E5-24378-00	PIPE, JOINT 3	1	1	1	1	
12	69J-24461-00	PIPE, JOINT	1	1	1	1	
13	69J-24315-00	PIPE 5	1	1	1	1	
14	69J-13976-00	PIPE, FUEL 6	1	1	1	1	
15	68V-24387-00	CLIP	1	1	1	1	
16	69J-24501-10	FILTER, FUEL	1	1	1	1	
17	69J-24599-10	CAP	1	1	1	1	
18	69J-24325-20	PIPE 14	1	1	1	1	
19	69J-1410F-00	NIPPLE 1	1	1	1	1	
20	69J-24366-00	CLAMP, FUEL PIPE 1	1	1	1	1	
21	69J-24367-00	CLAMP, FUEL PIPE 2	1	1	1	1	
22	98582-05008	SCREW, PAN HEAD	2	2	2	2	
23	69J-13974-00	PIPE, FUEL 4	1	1	1	1	
24	69J-24381-00	SET BAR, FUEL JOINT	1	1	1	1	





FIG. 14 FUEL 1

REF. NO.	PART NO.	DESCRIPTION	68J5	60L5	69K5	60M5	REMARKS
1	689-85547-00	DAMPER	1	1	1	1	
2	90445-13004	HOSE (L2360)	1	1	1	1	
3	6R3-24377-00	PIPE, JOINT 3	1	1	1	1	
4	90465-11M10	CLAMP	4	4	4	4	
5	61A-24311-00	PIPE, FUEL 1	1	1	1	1	
6	65L-24560-00	FILTER ASSY	1	1	1	1	
7	61A-24521-00	.CUP, FILTER	1	1	1	1	
8	65L-24531-01	.NUT	1	1	1	1	
9	61A-24564-00	.O-RING	1	1	1	1	
10	65L-24577-00	.SPRING	1	1	1	1	
11	65L-24563-00	.ELEMENT, FILTER	1	1	1	1	
12	61A-24469-00	.FLOAT, WATER LEVEL	1	1	1	1	
13	65L-24564-00	.O-RING	1	1	1	1	
14	97095-06014	BOLT	1	1	1	1	
15	92995-06600	WASHER	1	1	1	1	
16	97095-06016	BOLT	1	1	1	1	
17	92995-06100	WASHER, SPRING	1	1	1	1	
18	90201-06068	WASHER, PLATE	1	1	1	1	
19	65L-24558-00	HOLDER, FILTER	1	1	1	1	
20	69J-24566-00	BRACKET, FILTER	1	1	1	1	
21	90119-06037	BOLT, WITH WASHER	2	2	2	2	
22	69J-24313-00	PIPE 3	1	1	1	1	
23	90465-11M10	CLAMP	1	1	1	1	
24	6R3-24377-10	PIPE, JOINT 3	1	1	1	1	FOR USA
25	90465-11M10	CLAMP	1	1	1	1	FOR USA
26	61H-2819R-31	TAG, WARNING	1	1	1	1	
27	69J-28100-01	TOOL KIT	1	1	1	1	AP



67F0100-1100

FIG. 15 FUEL 2

[illegible]

E1




FIG. 16 GENERATOR

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-81450-10	ROTOR ASSY	1	1	1	1	
2	69J-81460-01	BASE ASSY	1	1	1	1	
3	69J-85580-00	.COIL, PULSER	1	1	1	1	
4	69J-81410-10	.STATOR ASSY	1	1	1	1	
5	63D-81345-20	.SCREW, WITH WASHER (M6X30)	4	4	4	4	
6	99530-08012	PIN, DOWEL	2	2	2	2	
7	97095-06035	BOLT	4	4	4	4	
8	92995-06100	WASHER, SPRING	4	4	4	4	
9	92995-06600	WASHER	4	4	4	4	
10	90280-05015	KEY, WOODRUFF	1	1	1	1	
11	90201-24014	WASHER, PLATE	1	1	1	1	
12	90179-24002	NUT	1	1	1	1	
13	69J-81673-00	ROTOR	1	1	1	1	
14	6P2-81332-00	PLATE, TIMING	1	1	1	1	
15	97885-06010	SCREW, PAN HEAD	1	1	1	1	
16	92995-06600	WASHER	1	1	1	1	
17	69J-8132G-00	PLATE	1	1	1	1	
18	97095-06016	BOLT	1	1	1	1	
19	92995-06600	WASHER	1	1	1	1	
20	90465-14M66	CLAMP	3	3	3	3	
21	69J-81337-00	COVER, FLYWHEEL	1	1	1	1	
22	663-82317-01	DAMPER, IGNITION COIL	2	2	2	2	
23	6A0-82317-00	DAMPER, IGNITION COIL	3	3	3	3	
24	90387-06119	COLLAR	3	3	3	3	
25	90119-06M59	BOLT, WITH WASHER	3	3	3	3	
26	67F-2812A-00	PULLER, FUSE	1	1	1	1	
27	69J-81919-20	GRAPHIC, REGULATOR	1	1	1	1	




FIG. 17 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-82316-00	BRACKET, IGNITION COIL	1	1	1	1	
2	90480-09M21	GROMMET	1	1	1	1	
3	90119-06041	BOLT, WITH WASHER	6	6	6	6	
4	69J-82310-00	IGNITION COIL ASSY	3	3	3	3	
5	97095-06020	BOLT	6	6	6	6	
6	92995-06600	WASHER	6	6	6	6	
7	90464-12002	CLAMP	3	3	3	3	
8	90464-07M56	CLAMP	3	3	3	3	
9	69J-82314-00	COVER, IGNITION COIL	1	1	1	1	
10	90110-06038	BOLT, HEXAGON SOCKET HEAD	4	4	4	4	
11	663-82317-01	DAMPER, IGNITION COIL	2	2	2	2	
12	69J-81960-11	RECTIFIER & REGULATOR ASSY	1	1	1	1	
13	69J-81975-A0	PLATE, RECTIFIER FITTING	1	1	1	1	
14	69J-81972-01-1S	COVER, RECTIFIER	1	1	1	1	
15	90119-06MA3	BOLT, WITH WASHER	4	4	4	4	
16	90119-06MA5	BOLT, WITH WASHER	2	2	2	2	
17	97095-06020	BOLT	1	1	1	1	
18	92995-06100	WASHER, SPRING	1	1	1	1	
19	92995-06600	WASHER	1	1	1	1	
20	69J-12482-00	PIPE 2	1	1	1	1	
21	69J-12481-00	PIPE 1	1	1	1	1	
22	90467-09M03	CLIP	2	2	2	2	
23	90467-08M18	CLIP	2	2	2	2	
24	69J-82519-00	WIRE, EARTH LEAD	1	1	1	1	
25	97095-06012	BOLT	2	2	2	2	
26	92995-06600	WASHER	2	2	2	2	
27	61A-85790-00	THERMOSENSOR ASSY	1	1	1	1	




FIG. 18 ELECTRICAL 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-8591A-31	ENGINE CONTROL UNIT ASSY	1		1		FOR USA,CAN
	69J-8591A-11	ENGINE CONTROL UNIT ASSY	1	1			FOR OCE,CAR
	60L-8591A-31	ENGINE CONTROL UNIT ASSY		1	1		FOR USA,CAN
	60L-8591A-11	ENGINE CONTROL UNIT ASSY		1	1		FOR OCE,CAR
2	97095-06016	BOLT	2	2	2	2	
3	92995-06600	WASHER	2	2	2	2	
4	97095-06020	BOLT	2	2	2	2	
5	92995-06600	WASHER	2	2	2	2	
6	69J-81925-00	TERMINAL	1	1	1	1	
7	97095-08020	BOLT	1	1	1	1	
8	92995-08600	WASHER	1	1	1	1	
9	97095-06014	BOLT	1	1	1	1	
10	92995-06600	WASHER	1	1	1	1	
11	69J-81948-00	BRACKET	1	1	1	1	
12	69J-82588-00	PLATE	1	1	1	1	
13	6A0-82317-00	DAMPER, IGNITION COIL	6	6	6	6	
14	90387-06119	COLLAR	6	6	6	6	
15	90119-06M59	BOLT, WITH WASHER	6	6	6	6	
16	68V-8194A-00	RELAY	1	1	1	1	
17	97095-06010	BOLT	2	2	2	2	
18	92995-06100	WASHER, SPRING	2	2	2	2	
19	92995-06600	WASHER	2	2	2	2	
20	68V-81953-00	STAY, RELAY	1	1	1	1	
21	97780-60620	SCREW, TAPPING	1	1	1	1	
22	6G5-82119-00	COVER, LEAD WIRE	1	1	1	1	
23	69J-81950-11	RELAY ASSY	1	1	1	1	
24	97095-06010	BOLT	2	2	2	2	




FIG. 18 ELECTRICAL 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
25	92995-06100	WASHER, SPRING	2	2	2	2	
26	92995-06600	WASHER	2	2	2	2	
27	97013-06025	BOLT	2	2	2	2	
28	92903-06600	WASHER, PLATE	2	2	2	2	
29	69J-81942-00	COVER	1	1	1	1	
30	90169-05M00	SCREW, TRUSS HEAD TAPPING	4	4	4	4	
31	90464-07M56	CLAMP	2	2	2	2	
32	90465-14M66	CLAMP	6	6	6	6	
33	68V-81950-00	RELAY ASSY	1	1	1	1	
34	97780-60625	SCREW, TAPPING	1	1	1	1	
35	90464-18004	CLAMP	1	1	1	1	
36	69J-8366G-01	BRACKET 3	1	1	1	1	FOR USA,CAN
37	90109-06M86	BOLT	1	1	1	1	FOR USA,CAN
38	90465-08049	CLAMP	1	1	1	1	FOR USA,CAN
39	90462-08024	CLAMP	1	1	1	1	FOR USA,CAN
40	90464-18004	CLAMP	1	1	1	1	FOR USA,CAN
41	69J-81919-00	GRAPHIC, REGULATOR	1	1	1	1	
42	97095-08020	BOLT	1	1	1	1	AP
43	92995-08600	WASHER	1	1	1	1	AP
44	97095-06014	BOLT	1	1	1	1	AP
45	92995-06600	WASHER	1	1	1	1	AP
46	69J-82105-00	WIRE HARNESS	1	1	1	1	AP




FIG. 19 ELECTRICAL 3

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-82590-51	WIRE HARNESS ASSY	1	1	1	1	FOR USA,CAN
	69J-82590-21	WIRE HARNESS ASSY	1	1	1	1	FOR OCE,CAR
2	67F-82151-20	.FUSE (5A)	2	2	2	2	
3	69J-8215B-00	.CAP (BROWN)	1	1	1	1	
4	90465-14M66	CLAMP	1	1	1	1	
5	97095-06020	BOLT	2	2	2	2	
6	92995-06100	WASHER, SPRING	2	2	2	2	
7	92995-06600	WASHER	2	2	2	2	
8	97095-06035	BOLT	3	3	3	3	
9	92995-06600	WASHER	3	3	3	3	
10	69J-82563-00	TRIM & TILT SWITCH ASSY	1	1	1	1	
11	69J-42723-00-8D	COVER, BOTTOM	1	1	1	1	
12	69J-82587-00	GASKET	2	2	2	2	
13	69J-83614-10	BRACKET	2	2	2	2	
14	90109-06M86	BOLT	4	4	4	4	
15	69J-8259N-11	WIRE HARNESS ASSY 3	1	1	1	1	
16	67F-8215B-10	.CAP (YELLOW)	2	2	2	2	
17	67F-8215B-20	.CAP (GREEN)	5	5	5	5	
18	67F-82151-00	.FUSE (20A)	4	4	4	4	
19	67F-82151-10	.FUSE (30A)	10	10	10	10	
20	69J-83306-01	DRIVE UNIT ASSY	1	1	1	1	
21	90109-06M82	BOLT	2	2	2	2	
22	69J-81315-00	LEAD WIRE ASSY	1	1	1	1	
23	90465-14M66	CLAMP	1	1	1	1	
24	69J-81949-00	WIRE, LEAD (ISOLATOR CABLE)	1	1	1	1	AP




FIG. 20 STARTING MOTOR

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-81800-00	STARTING MOTOR ASSY	1	1	1	1	
2	67F-81850-00	.ARMATURE ASSY	1	1	1	1	
3	67F-81810-00	.STATOR ASSY	1	1	1	1	
4	69J-81840-00	.BRUSH HOLDER ASSY	1	1	1	1	
5	69J-81801-00	..BRUSH SET	1	1	1	1	
6	67F-81813-00	..SPRING, BRUSH	4	4	4	4	
7	68F-81820-00	.REAR BRACKET ASSY	1	1	1	1	
8	67F-81808-00	.PINION ASSY	1	1	1	1	
9	67F-81857-00	.PINION STOPPER SET	1	1	1	1	
10	67F-81807-00	.GEAR ASSY, STARTING MOTOR	1	1	1	1	
11	67F-81832-00	..CLUTCH, OVER RUN	1	1	1	1	
12	67F-81836-00	..SHAFT, PINION	1	1	1	1	
13	67F-81821-00	..BRACKET, CENTER 1	1	1	1	1	
14	67F-81841-00	..BEARING	1	1	1	1	
15	67F-81891-00	..GEAR, RING	1	1	1	1	
16	67F-8183R-00	...GASKET	1	1	1	1	
17	67F-81830-00	..BRACKET, CENTER 2	1	1	1	1	
18	60V-8183T-00	..GEAR, IDLER	3	3	3	3	
19	67F-81809-00	..WASHER KIT	1	1	1	1	
20	69J-81842-00	.COVER	1	1	1	1	
21	69J-81839-00	.LEVER ASSY	1	1	1	1	
22	69J-81941-00	.STARTER RELAY ASSY	1	1	1	1	
23	69J-81869-00	.COVER, DUST	1	1	1	1	
24	6K7-81826-10	.BOLT	2	2	2	2	
25	69J-81828-00	.BOLT 2	2	2	2	2	
26	67F-81846-00	.SCREW	2	2	2	2	
27	97013-08045	BOLT	3	3	3	3	




FIG. 20 STARTING MOTOR

[illegible]




FIG. 21 BOTTOM COWLING 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-42710-02-8D	BOTTOM COWLING ASSY	1	1	1	1	
2	69J-42738-02-5B	PLATE, FITTING	1	1	1	1	
3	6P2-42717-00	RUBBER, SEAL 2	1	1	1	1	
4	6P2-42718-00	RUBBER, SEAL 3	1	1	1	1	
5	69J-42744-11	STAY	1	1	1	1	
6	97885-06010	SCREW, PAN HEAD	1	1	1	1	
7	90109-06M82	BOLT	2	2	2	2	
8	69J-42725-01	GROMMET	1	1	1	1	FOR CAN,CAR
9	90465-13M30	CLAMP	1	1	1	1	
10	64D-42738-10-5B	PLATE, FITTING	1	1	1	1	
11	90109-06M82	BOLT	1	1	1	1	
12	6P2-42615-00	SEAL	1	1	1	1	
13	69J-42716-00	RUBBER, SEAL 1	1	1	1	1	
14	90119-08M22	BOLT, WITH WASHER	4	4	4	4	
15	90480-22M81	GROMMET	8	8	8	8	
16	90387-08M37	COLLAR	4	4	4	4	
17	6H1-42726-21	GROMMET	1	1	1	1	
18	90465-11M10	CLAMP	2	2	2	2	
19	61A-42727-00	GROMMET	1	1	1	1	
20	6P2-44391-00	NIPPLE, HOSE	1	1	1	1	
21	69J-42717-00	RUBBER, SEAL 2	2	2	2	2	
22	61A-42717-00	RUBBER, SEAL 2	2	2	2	2	
23	6E5-82588-00	PLATE	3	3	3	3	
24	90109-06M81	BOLT	3	3	3	3	
25	90462-20001	CLAMP	1	1	1	1	
26	90109-06M86	BOLT	1	1	1	1	
27	69J-82554-01	STAY, NEUTRAL SWITCH	1	1	1	1	




FIG. 21 BOTTOM COWLING 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
28	90109-06M86	BOLT	1	1	1	1	
29	90464-09M47	CLAMP	1	1	1	1	
30	68F-42828-03-94	PLATE, CLAMP	1	1	1	1	
31	69J-42828-02-94	PLATE, CLAMP	1	1	1	1	
32	90109-06M82	BOLT	4	4	4	4	
33	6H4-42748-00	GROMMET	2	2	2	2	
34	69J-42815-00-8D	LEVER, CLAMP	1	1	1	1	
35	69J-42817-00-8D	LEVER, CLAMP	1	1	1	1	
36	90386-15M73	BUSH	4	4	4	4	
37	90206-15M18	WASHER, WAVE	2	2	2	2	
38	68F-42818-01	LEVER, CLAMP	2	2	2	2	
39	97095-06020	BOLT	2	2	2	2	
40	90201-06068	WASHER, PLATE	2	2	2	2	
41	69J-42828-10-94	PLATE, CLAMP	1	1	1	1	
42	90109-06M82	BOLT	2	2	2	2	
43	69J-42816-00-8D	LEVER, CLAMP	1	1	1	1	
44	90386-15M73	BUSH	2	2	2	2	
45	90206-15M18	WASHER, WAVE	1	1	1	1	
46	6D8-42818-00	LEVER, CLAMP	1	1	1	1	
47	97095-06020	BOLT	1	1	1	1	
48	90201-06068	WASHER, PLATE	1	1	1	1	
49	64D-43144-00	HOOK, SPRING	3	3	3	3	
50	90109-06M86	BOLT	3	3	3	3	
51	90506-16M34	SPRING, TENSION	3	3	3	3	
52	68F-42753-00	FASTNER	1	1	1	1	AP FOR USA,OCE
53	90464-20258	CLAMP	1	1	1	1	AP FOR USA,OCE
54	68V-82594-00	CLAMP	1	1	1	1	




FIG. 22 BOTTOM COWLING 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-42741-00-8D	APRON	1	1	1	1	
2	90173-06001	NUT, SQUARE	2	2	2	2	
3	69J-42771-00-8D	APRON	1	1	1	1	
4	90111-06025	BOLT	5	5	5	5	
5	90111-06026	BOLT	1	1	1	1	
6	90480-14M17	GROMMET	6	6	6	6	
7	69J-42774-00	STAY, APRON 1	6	6	6	6	
8	69J-45151-00-8D	COVER, UPPER CASING	1	1	1	1	
9	90111-06025	BOLT	2	2	2	2	
10	6E5-24379-00	PIPE, JOINT 4	1	1	1	1	
11	90445-11012	HOSE (L600)	1	1	1	1	
12	90447-13009	HOSE, WITH SPRING	1	1	1	1	
13	68T-12572-00	ADAPTER	1	1	1	1	
14	6R3-12581-00	JOINT, HOSE 1	1	1	1	1	
15	6R3-12582-00	JOINT, HOSE 2	1	1	1	1	
16	6R3-12583-00	GASKET, HOSE JOINT	1	1	1	1	
17	90445-11028	HOSE (L1050)	1	1	1	1	
18	90465-11M10	CLAMP	4	4	4	4	
19	97780-60520	SCREW, TAPPING	2	2	2	2	





FIG. 23 CONTROL 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-48531-00	BRACKET, REMOTE CONTROL 1	1	1	1	1	
2	90109-06M86	BOLT	1	1	1	1	
3	6E5-48344-00	CABLE END, REMOTE CONTROL	1	1	1	1	
4	90468-18008	CLIP	1	1	1	1	
5	69J-44117-00-1S	BRACKET	1	1	1	1	
6	97095-06035	BOLT	2	2	2	2	
7	92995-06600	WASHER	2	2	2	2	
8	69J-44176-01-1S	BRACKET	1	1	1	1	
9	93700-06M01	NIPPLE, GREASE	1	1	1	1	
10	90386-12069	BUSH	2	2	2	2	
11	90109-08019	BOLT	1	1	1	1	
12	90508-20020	SPRING, TORSION	1	1	1	1	
13	60V-8259F-00	SWITCH ASSY	1	1	1	1	
14	69J-8259F-00	SWITCH ASSY	1	1	1	1	
15	61A-82588-01	PLATE	2	2	2	2	
16	97885-04016	SCREW, PAN HEAD	4	4	4	4	
17	92995-04100	WASHER	4	4	4	4	
18	90465-11M10	CLAMP	1	1	1	1	
19	90465-06M86	CLAMP	1	1	1	1	
20	90464-09010	CLAMP	1	1	1	1	
21	6P2-44121-00	LEVER, SHIFT ROD	1	1	1	1	
22	69J-44122-00	BUSHING, SHIFT ROD LEVER	1	1	1	1	
23	90202-08M20	WASHER, PLATE	1	1	1	1	
24	90468-18008	CLIP	2	2	2	2	
25	90386-06M12	BUSH	1	1	1	1	
26	69J-44118-00	BRACKET	1	1	1	1	
27	648-42715-00	BUSHING	1	1	1	1	



69J5100-E240

FIG. 24 CONTROL 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-42154-00	LEVER, THROTTLE CONTROL	1	1	1	1	
2	68V-42171-00	BUSHING	1	1	1	1	
3	90386-10001	BUSH	3	3	3	3	
4	90202-10002	WASHER, PLATE	1	1	1	1	
5	93410-10082	CIRCLIP	1	1	1	1	
6	69J-42152-00-94	GEAR	2	2	2	2	
7	91690-30025	PIN, SPRING	2	2	2	2	
8	91690-30018	PIN, SPRING	2	2	2	2	
9	69J-42153-00	SHAFT, THROTTLE CONTROL	1	1	1	1	
10	69J-41632-00-94	LEVER, MAGNETO CONTROL	1	1	1	1	
11	663-85518-00	JOINT, BALL	1	1	1	1	
12	90201-10M02	WASHER, PLATE	2	2	2	2	
13	6E5-48344-00	CABLE END, REMOTE CONTROL	1	1	1	1	
14	90468-18008	CLIP	1	1	1	1	
15	69J-41661-00-94	BRACKET	1	1	1	1	
16	97095-06045	BOLT	5	5	5	5	
17	92995-06600	WASHER	5	5	5	5	
18	90465-06M86	CLAMP	1	1	1	1	
19	97095-06014	BOLT	2	2	2	2	
20	92995-06600	WASHER	2	2	2	2	
21	69J-82581-00	STAY, CORD CLAMP	1	1	1	1	
22	90464-13249	CLAMP	1	1	1	1	
23	676-41662-00	BRACKET	1	1	1	1	
24	97095-06020	BOLT	2	2	2	2	
25	92995-06600	WASHER	2	2	2	2	
26	69J-41213-00	CAM, ACCEL.	1	1	1	1	
27	69J-44135-00	SPRING	1	1	1	1	




FIG. 25 CONTROL 3

[illegible]




FIG. 26 BRACKET 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-43111-01-8D	BRACKET, CLAMP 1	1	1	1	1	
2	6G5-45251-02	ANODE	1	1	1	1	
3	6G5-44526-00	PLATE	2	2	2	2	
4	97095-06025	BOLT	4	4	4	4	
5	92995-06600	WASHER	4	4	4	4	
6	6H1-82148-00	WIRE, LEAD 4	1	1	1	1	
7	97095-06010	BOLT	1	1	1	1	
8	92995-06600	WASHER	1	1	1	1	
9	6E5-82148-00	WIRE, LEAD 4	1	1	1	1	
10	97885-06012	SCREW, PAN HEAD	1	1	1	1	
11	92995-06600	WASHER	1	1	1	1	
12	61A-43132-00	WASHER, FRICTION	1	1	1	1	
13	97885-06010	SCREW, PAN HEAD	2	2	2	2	
14	69J-43112-01-8D	BRACKET, CLAMP 2	1	1	1	1	
15	61A-43133-00	WASHER, FRICTION	1	1	1	1	
16	97885-06010	SCREW, PAN HEAD	2	2	2	2	
17	93700-06M03	NIPPLE, GREASE	1	1	1	1	
18	90465-08M83	CLAMP	1	1	1	1	
19	97885-06012	SCREW, PAN HEAD	1	1	1	1	
20	92995-06600	WASHER	1	1	1	1	
21	6R3-43131-00	BOLT, CLAMP BRACKET	1	1	1	1	
22	90386-25M31	BUSH	2	2	2	2	
23	90201-26M59	WASHER, PLATE	2	2	2	2	
24	90185-22M11	NUT, SELF-LOCKING	1	1	1	1	
25	90465-11M10	CLAMP	4	4	4	4	
26	90465-08M83	CLAMP	1	1	1	1	
27	97095-06014	BOLT	1	1	1	1	




FIG. 26 BRACKET 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
28	92995-06600	WASHER	1	1	1	1	
29	90119-10024	BOLT, WITH WASHER	8	8	8	8	
30	61A-43311-21-8D	BRACKET, SWIVEL 1	1	1	1	1	
31	93700-06M03	NIPPLE, GREASE	5	5	5	5	
32	69J-82147-00	WIRE, LEAD 4	1	1	1	1	
33	6G5-43144-00	HOOK, SPRING	1	1	1	1	
34	97095-06010	BOLT	1	1	1	1	
35	61A-43181-01	LEVER, TILT STOP	1	1	1	1	
36	6G5-43185-02	LEVER, TILT STOP	1	1	1	1	
37	90386-10M16	BUSH	4	4	4	4	
38	6G5-43148-00	COLLAR, DISTANCE	2	2	2	2	
39	90249-06M19	PIN	1	1	1	1	
40	90387-10M02	COLLAR	1	1	1	1	
41	91690-30020	PIN, SPRING	2	2	2	2	
42	90506-16003	SPRING, TENSION	1	1	1	1	
43	6E5-43126-02	PIN, UPPER SHOCK MOUNT	1	1	1	1	
44	90386-18M63	BUSH	2	2	2	2	
45	90386-18M14	BUSH	2	2	2	2	
46	93410-18M02	CIRCLIP	1	1	1	1	
47	63V-82377-50	LABEL (SPARK,IGNITION)	1	1	1	1	FOR CAN
48	90101-12M05	BOLT (L:130MM)	4	4	4	4	UR
	90101-12M77	BOLT (L:150MM)	2	2	2	2	UR EXCEPT CAR
49	90201-13M01	WASHER, PLATE	8	8	8	8	
50	90201-12M05	WASHER, PLATE	4	4	4	4	
51	95380-12600	NUT	8	8	8	8	




FIG. 27 BRACKET 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-83672-10	TRIM SENDER	1	1	1	1	FOR USA,CAN
	69J-83672-00	TRIM SENDER	1	1	1	1	FOR OCE,CAR
2	703-82119-00	COVER, LEAD WIRE	1	1	1	1	FOR OCE,CAR
3	97885-06016	SCREW, PAN HEAD	2	2	2	2	
4	61A-43376-00	BOLT, THRUST RECEIVER	2	2	2	2	
5	95780-10300	NUT, FLANGE	2	2	2	2	
6	69J-42510-00-8D	STEERING BRACKET ASSY	1	1	1	1	
7	90201-40M00	WASHER, PLATE	2	2	2	2	
8	90386-39M89	BUSH	2	2	2	2	
9	93210-35321	O-RING	1	1	1	1	
10	90202-40M47	WASHER, PLATE	1	1	1	1	
11	69J-44551-00-8D	HOUSING, LOWER MOUNT RUBBER	1	1	1	1	
12	93410-37M04	CIRCLIP	1	1	1	1	
13	61A-44575-00	DAMPER, LOWER MOUNT RUBBER	1	1	1	1	
14	66K-44555-00-94	MOUNT DAMPER, LOWER SIDE	2	2	2	2	
15	90202-32M19	WASHER, PLATE	2	2	2	2	
16	90201-16016	WASHER, PLATE	2	2	2	2	
17	6E5-82149-00	WIRE, LEAD 3	1	1	1	1	
18	90101-14002	BOLT	2	2	2	2	
19	90201-15M58	WASHER, PLATE	2	2	2	2	
20	90185-14M00	NUT, SELF-LOCKING	2	2	2	2	
21	92995-14600	WASHER	2	2	2	2	
22	61A-44552-01-94	HOUSING, LOWER MOUNT RUBBER	2	2	2	2	
23	90119-10024	BOLT, WITH WASHER	4	4	4	4	
24	69J-44514-00-94	MOUNT DAMPER, UPPER SIDE	2	2	2	2	
25	90201-16015	WASHER, PLATE	2	2	2	2	
26	90202-28M46	WASHER, PLATE	2	2	2	2	




FIG. 27 BRACKET 2

[illegible]




FIG. 28 POWER TRIM & TILT ASSY 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-43800-01-4D	POWER TRIM & TILT ASSY	1	1	1	1	
2	69J-43840-01	POWER TILT ASSY	1	1	1	1	
3	69J-43810-01	.TILT PISTON SUB ASSY	1	1	1	1	
4	69J-43801-00	..ROD	1	1	1	1	
5	93106-19N50	..OIL SEAL	1	1	1	1	
6	6H1-43861-00	..O-RING	1	1	1	1	
7	6H1-43872-00	..RING, BACK UP	1	1	1	1	
8	61A-4389H-00	..O-RING	1	1	1	1	
9	61A-43811-00	..SCREW, CYLINDER END	1	1	1	1	
10	69J-4384H-00	..SPRING	1	1	1	1	
11	69J-4382E-00	..ADAPTOR 2	1	1	1	1	
12	69J-4380P-01	..PISTON SUB ASSY	1	1	1	1	
13	93505-32038	...BALL	5	5	5	5	
14	61A-43861-00	...O-RING	1	1	1	1	
15	61A-43871-00	...RING, BACK UP	1	1	1	1	
16	61A-43861-00	.O-RING	1	1	1	1	
17	6H1-43814-00	.PISTON, FREE	1	1	1	1	
18	61A-43813-01	.CYLINDER, TILT	1	1	1	1	
19	61A-43835-01	PIPE	1	1	1	1	
20	69J-4388J-00	PLUG 2	1	1	1	1	
21	69J-43833-00	PIPE	1	1	1	1	
22	93210-17239	O-RING	1	1	1	1	
23	69J-4388E-00	BOLT ,SCREW	1	1	1	1	
24	90386-18M14	BUSH	2	2	2	2	
25	61A-43818-00	PIN, LOWER SHOCK MOUNT	1	1	1	1	
26	61A-43876-00	RING, SNAP	1	1	1	1	
27	93210-18397	O-RING	1	1	1	1	




FIG. 28 POWER TRIM & TILT ASSY 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
28	69J-43845-00	SCREW, MANUAL RELEASE	1	1	1	1	
29	6H1-43875-00	RING, SNAP	1	1	1	1	
30	69J-4381C-00	FILTER 3	2	2	2	2	
31	69J-43899-00	PLATE STOPPER	2	2	2	2	
32	69J-4389J-00	O-RING	2	2	2	2	
33	69J-43830-01	GEAR PUMP ASSY	1	1	1	1	
34	93505-32038	.BALL	4	4	4	4	
35	69J-4381C-00	.FILTER 3	1	1	1	1	
36	69J-4389J-00	.O-RING	2	2	2	2	
37	93503-16003	.BALL	2	2	2	2	
38	69J-4384M-00	.PISTON, SHUTTLE 2	1	1	1	1	
39	69A-4384F-00	.SEAL, MAIN VALVE	2	2	2	2	
40	99001-03600	.CIRCLIP	2	2	2	2	
41	69J-43894-00	.SPRING, SHUTTLE RETURN	2	2	2	2	
42	69J-43841-00	.PISTON, SHUTTLE	1	1	1	1	
43	6H1-43883-00	.O-RING	1	1	1	1	
44	60V-4386A-00	.PIN, ABSORBER VALVE	2	2	2	2	
45	69J-43853-00	.SPRING, MAIN VALVE	2	2	2	2	
46	69J-43893-00	.WASHER	2	2	2	2	
47	93501-08001	.BALL	2	2	2	2	
48	93210-08391	.O-RING	1	1	1	1	
49	69J-43851-00	.SEAT, RELIEF VALVE	1	1	1	1	
50	69J-43844-00	.PIN, VALVE SUPPORT	1	1	1	1	
51	93210-064A5	.O-RING	1	1	1	1	
52	69J-43855-00	.SPRING, UP RELIEF	1	1	1	1	
53	69J-43843-00	.SCREW, VALVE LOCK	2	2	2	2	
54	6H1-4384G-11	.SEAL, RELIEF VALVE	1	1	1	1	




FIG. 28 POWER TRIM & TILT ASSY 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
55	6H1-43844-10	.PIN, VALVE SUPPORT	1	1	1	1	
56	6H1-43856-10	.SPRING, DOWN RELIEF	1	1	1	1	
57	69J-43854-00	.SPRING, MANUAL RELEASE	1	1	1	1	
58	69J-4384G-00	.SEAL, RELIEF VALVE	1	1	1	1	
59	CS3-4387G-00	.WASHER	2	2	2	2	
60	91318-05025	.BOLT	2	2	2	2	
61	93604-35236	.PIN, DOWEL	2	2	2	2	
62	69J-43871-00	RING, BACK UP	1	1	1	1	
63	69J-43816-00	FILTER 1	1	1	1	1	
64	69J-4381J-00	PLATE	1	1	1	1	
65	91318-05040	BOLT	3	3	3	3	
66	69J-43831-00	CONNECTOR, SHAFT	1	1	1	1	
67	61A-43861-00	O-RING	2	2	2	2	
68	6T4-43875-01	RING, SNAP	2	2	2	2	
69	61A-43822-00	SEAL, TRIM DUST	2	2	2	2	
70	61A-43821-00	SCREW, TRIM CYLINDER END	2	2	2	2	
71	69J-43820-00	TRIM PISTON SUB ASSY	2	2	2	2	
72	61A-43874-00	.RING, BACK UP	1	1	1	1	
73	61A-43864-00	.O-RING	1	1	1	1	
74	61A-4384H-10	.SPRING	1	1	1	1	
75	61A-43875-10	.RING, SNAP	1	1	1	1	




FIG. 29 POWER TRIM & TILT ASSY 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-43880-00	MOTOR ASSY	1	1	1	1	
2	90206-14N50	.WASHER, WAVE	1	1	1	1	
3	93399-999T6	.BEARING	2	2	2	2	
4	69J-43805-00	.ARMATURE ASSY	1	1	1	1	
5	69J-43804-00	.STATOR ASSY	1	1	1	1	
6	69J-43861-00	.O-RING	1	1	1	1	
7	69J-43886-00	.BOLT	2	2	2	2	
8	69J-43882-00	.OIL SEAL	1	1	1	1	
9	69J-43891-00	.BRUSH 1	4	4	4	4	
10	69J-4386K-00	.SPRING, BRUSH	4	4	4	4	
11	69J-43881-00	.FRAME, END	1	1	1	1	
12	69J-4388H-00	PLUG	1	1	1	1	
13	69J-43817-00	FILTER 2	1	1	1	1	
14	69J-4388F-00	SPACER	1	1	1	1	
15	6H1-43869-00	O-RING	2	2	2	2	
16	69J-43828-00	BODY, RESERVOIR	1	1	1	1	
17	69J-43888-00	BOLT, SOCKET	6	6	6	6	
18	93210-09165	O-RING	1	1	1	1	
19	6H1-43829-00	PLUG, RESERVOIR	1	1	1	1	




FIG. 30 UPPER CASING

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-41137-02-94	GUIDE, EXHAUST	1	1	1	1	
2	90119-08M79	BOLT, WITH WASHER	2	2	2	2	
3	97075-10045	BOLT	7	7	7	7	
4	92995-10600	WASHER	7	7	7	7	
5	97575-10535	BOLT, WITH WASHER	7	7	7	7	
6	93608-16M16	PIN, DOWEL	2	2	2	2	
7	6E5-42724-00	GROMMET	1	1	1	1	
8	69J-11371-00	COVER	1	1	1	1	
9	93210-28543	.O-RING	1	1	1	1	
10	93210-33MG4	.O-RING	1	1	1	1	
11	69J-12233-00	PLATE, GUIDE STOPPER 1	1	1	1	1	
12	90387-06037	COLLAR	1	1	1	1	
13	97095-06020	BOLT	1	1	1	1	
14	92995-06600	WASHER	1	1	1	1	
15	69J-41131-10-94	MANIFOLD, EXT. 1	1	1	1	1	
16	93608-16M16	PIN, DOWEL	2	2	2	2	
17	69J-41132-10-5B	MANIFOLD, EXHAUST	1	1	1	1	
18	6P2-41134-00	GASKET, EXHAUST MANIFOLD	1	1	1	1	
19	97575-08590	BOLT, WITH WASHER	4	4	4	4	
20	69J-41138-00	SEAL, EXT. 1	1	1	1	1	
21	69J-41135-A0	GASKET, EXHAUST MANIFOLD	1	1	1	1	
22	69J-45181-00-5B	PLATE	1	1	1	1	
23	6S1-41136-00	GASKET, EXHAUST MANIFOLD 4	1	1	1	1	
24	69J-14711-10-5B	MUFFLER 1	1	1	1	1	
25	97075-08035	BOLT	10	10	10	10	
26	92995-08600	WASHER	10	10	10	10	
27	93606-19M23	PIN, DOWEL	2	2	2	2	




FIG. 30 UPPER CASING

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
28	69J-45127-00	SEAL	1	1	1	1	
29	69J-45123-00	GASKET, MUFFLER	1	1	1	1	
30	69J-45111-10-8D	CASING, UPPER	1	1	1	1	
31	69J-42769-00	SEAL, RUBBER	1	1	1	1	
32	69J-45113-20	GASKET, UPPER CASING	1	1	1	1	
33	90119-10007	BOLT, WITH WASHER	6	6	6	6	
34	93608-16M16	PIN, DOWEL	2	2	2	2	
35	69J-15316-00	DAMPER, ENGINE MOUNT 1	1	1	1	1	
36	69J-45152-00-8D	COVER, UPPER CASING 2	1	1	1	1	
37	97095-06014	BOLT	2	2	2	2	
38	69J-45318-01	BUSHING, DRIVE SHAFT	1	1	1	1	
39	93420-36M01	CIRCLIP	1	1	1	1	
40	61A-45155-00	CAP	1	1	1	1	
41	97095-06010	BOLT	1	1	1	1	
42	92995-06600	WASHER	1	1	1	1	
43	6E5-83558-00	END, NIPPLE	1	1	1	1	
44	90465-11M10	CLAMP	2	2	2	2	
45	90445-07010	HOSE (L1330)	1	1	1	1	X (25.3")
	90445-07012	HOSE (L1457)	1		1		U (30.3")
46	61A-45378-00	NIPPLE, HOSE	1	1	1	1	
47	93606-12019	PIN, DOWEL	1	1	1	1	
48	90119-06M17	BOLT, WITH WASHER	1	1	1	1	
49	69J-14624-01	COVER, EXHAUST	1	1	1	1	
50	97880-06016	SCREW, PAN HEAD	2	2	2	2	
51	92990-06600	WASHER, PLATE	2	2	2	2	
52	69J-15312-01	GASKET, OIL PAN	1	1	1	1	
53	69J-45211-01-8D	EXTENSION	1		1		U (30.3")





FIG. 30 UPPER CASING


[illegible]



69J4100-D310

FIG. 31 OIL PAN


REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-15311-00-5B	OIL PAN	1	1	1	1	
2	69J-15761-00	SEAL, RUBBER 1	1	1	1	1	
3	97575-08560	BOLT, WITH WASHER	10	10	10	10	
4	97095-08035	BOLT	2	2	2	2	
5	92995-08600	WASHER	2	2	2	2	
6	93608-16M16	PIN, DOWEL	2	2	2	2	
7	90340-14M06	PLUG, STRAIGHT SCREW	1	1	1	1	
8	90430-14M09	GASKET	1	1	1	1	
9	69J-13411-00	STRAINER, OIL	1	1	1	1	
10	90387-06M64	.COLLAR	3	3	3	3	
11	69J-13415-00	.SEAL, OIL STRAINER	1	1	1	1	
12	97027-06025	BOLT	3	3	3	3	
13	92907-06600	WASHER, PLATE	3	3	3	3	
14	69J-13300-00	OIL PUMP ASSY	1	1	1	1	
15	69J-13329-00	.GASKET, PUMP COVER	1	1	1	1	
16	69J-13338-00	.OIL SEAL	1	1	1	1	
17	69J-13119-00	.OIL SEAL	1	1	1	1	
18	69J-13631-00	.OIL SEAL	2	2	2	2	
19	69J-11355-00	SEAL, CYLINDER 1	1	1	1	1	
20	97575-06540	BOLT, WITH WASHER	4	4	4	4	
21	93210-25552	O-RING	2	2	2	2	
22	69J-15362-10	PLUG, OIL LEVEL	1	1	1	1	
23	69J-15377-00	GUIDE, INLET	1	1	1	1	
24	93210-19MJ3	O-RING	1	1	1	1	
25	97095-06020	BOLT	1	1	1	1	
26	92995-06100	WASHER, SPRING	1	1	1	1	
27	92995-06600	WASHER	1	1	1	1	



*1: APPLICABLE SERIAL NO.
60L: 1006395-, 69J: 1024101-

FIG. 32 LOWER CASING & DRIVE 1


REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-45300-22-8D	LOWER UNIT ASSY	1	1			X (25.3"),RH
	69J-45300-32-8D	LOWER UNIT ASSY	1				U (30.3"),RH
2	61A-45301-10-8D	CASING, LOWER	1	1			
3	93311-832V2	BEARING	1	1			
4	93332-000W1	BEARING	1	1			
5	61A-45567-00	SHIM (T:0.10MM)	1	1			UR
	61A-45567-10	SHIM (T:0.12MM)	1	1			UR
	61A-45567-20	SHIM (T:0.15MM)	1	1			UR
	61A-45567-30	SHIM (T:0.18MM)	1	1			UR
	61A-45567-40	SHIM (T:0.30MM)	1	1			UR
	61A-45567-50	SHIM (T:0.40MM)	1	1			UR
	61A-45567-60	SHIM (T:0.50MM)	1	1			UR
6	663-44366-00	DAMPER, WATER SEAL	1	1			
7	90340-08002	PLUG, STRAIGHT SCREW	1	1			
8	688-45341-10	PLUG, DRAIN	1	1			
9	90430-08020	GASKET	2	2			
10	61A-45376-00-94	GUIDE, SEAL DAMPER	1	1			
11	61A-45321-01	PLATE	1	1			
12	93210-64488	O-RING	1	1			
13	93106-09014	OIL SEAL	1	1			
14	90119-06M10	BOLT, WITH WASHER	3	3			
15	69J-44150-00	SHIFT CAM ASSY	1	1			
16	99001-08600	CIRCLIP	1	1			
17	90501-11M10	SPRING, COMPRESSION	1	1			
18	61A-44311-01	HOUSING, WATER PUMP	1	1			
19	61A-44322-02	INSERT, CARTRIDGE	1	1			
20	93210-86M38	O-RING	1	1			



*1: APPLICABLE SERIAL NO.
60L: 1006395-, 69J: 1024101-

FIG. 32 LOWER CASING & DRIVE 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
21	93210-37160	O-RING	1	1			
22	6E5-44365-00	DAMPER, WATER SEAL	1	1			
23	6E5-44312-00	COVER, WATER PUMP HOUSING	1	1			
24	6E5-44352-01	IMPELLER	1	1			
25	90280-04M05	KEY, WOODRUFF	1	1			
26	61A-45538-00	SPACER 1	1	1			
27	61A-45527-00	COLLAR, DRIVE SHAFT	1	1			
28	90201-22M01	WASHER, PLATE	2	2			
29	90206-22M19	WASHER, WAVE	1	1			
30	6G5-44323-00	OUTER PLATE, CARTRIDGE	1	1			
31	6E5-44315-A0	GASKET, WATER PUMP	1	1			
32	93606-12019	PIN, DOWEL	2	2			
33	90119-08M14	BOLT, WITH WASHER	4	4			
34	61A-45331-00-94	HOUSING, BEARING	1	1			
35	93101-28M16	OIL SEAL	2	2			
36	93317-330U2	BEARING	1	1			
37	61A-45587-00	SHIM (T:0.10MM)	1	1			UR
	61A-45587-10	SHIM (T:0.12MM)	1	1			UR
	61A-45587-20	SHIM (T:0.15MM)	1	1			UR
	61A-45587-30	SHIM (T:0.18MM)	1	1			UR
	61A-45587-40	SHIM (T:0.30MM)	1	1			UR
	61A-45587-50	SHIM (T:0.40MM)	1	1			UR
	61A-45587-60	SHIM (T:0.50MM)	1	1			UR
38	93341-930U9	BEARING	1	1			
39	93210-55M14	O-RING	1	1			
40	6E5-45344-00	COVER, OIL SEAL	1	1			
41	97095-08025	BOLT	4	4			



*1: APPLICABLE SERIAL NO.
60L: 1006395-, 69J: 1024101-

FIG. 32 LOWER CASING & DRIVE 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
42	92995-08600	WASHER	4	4			
43	69J-45501-00	DRIVE SHAFT COMP.	1	1			X (25.3")
	61A-45501-30	DRIVE SHAFT COMP.	1				U (30.3")
44	69J-45551-00	PINION (15T)	1	1			UR
45	90201-16M00	WASHER, PLATE	1	1			
46	90170-16M19	NUT	1	1			
47	69J-45560-00	GEAR 1 (30T)	1	1			UR
48	69J-45611-00	SHAFT, PROPELLER	1	1			
49	61A-45641-02	SHIFTER	1	1			
50	61A-45634-01	SLIDE, SHIFT	1	1			
51	61A-45632-00	PIN, CROSS	1	1			
52	69J-45631-00	CLUTCH, DOG	1	1			
53	61A-45633-00	RING, CROSS PIN	1	1			
54	6H1-45668-00	SHAFT, FREE	1	1			
55	61A-45635-00	PLUNGER, SHIFT	2	2			
56	90201-02M00	WASHER, PLATE	1	1			
57	90183-02M03	NUT, SPRING	2	2			
58	90501-10M77	SPRING, COMPRESSION	1	1			
59	93501-04011	BALL	2	2			
60	69J-45332-00-94	HOUSING, BEARING	1	1			
61	93306-210U0	BEARING	1	1			
62	69J-45571-00	GEAR 2 (30T)	1	1			UR
63	90201-31M00	WASHER, PLATE	1	1			
64	61A-45577-00	SHIM (T:0.10MM)	1	1			UR
	61A-45577-10	SHIM (T:0.12MM)	1	1			UR
	61A-45577-20	SHIM (T:0.15MM)	1	1			UR
	61A-45577-30	SHIM (T:0.18MM)	1	1			UR




**LOWER UNIT
ASSY**
(Fig. 32, Ref. No. 2 to 73
Fig. 33, Ref. No. 9)

69J3100C3111

*1: APPLICABLE SERIAL NO.
60L:1006395-, 69J: 1024101-

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
64	61A-45577-40	SHIM (T:0.30MM)	1	1			UR
	61A-45577-50	SHIM (T:0.40MM)	1	1			UR
	61A-45577-60	SHIM (T:0.50MM)	1	1			UR
65	93315-43061	BEARING	1	1			
66	93101-30M17	OIL SEAL	2	2			
67	93211-04384	O-RING	2	2			
68	90105-08036	BOLT, FLANGE	2	2			
69	90201-08023	WASHER, PLATE	2	2			
70	93700-09M00	NIPPLE, GREASE	1	1			
71	69J-45361-00-8D	CAP, LOWER CASING	1	1			
72	97095-08020	BOLT	2	2			
73	92995-08600	WASHER	2	2			
44	6P2-45551-01	PINION (15T)	1	1			UR *1
47	6P2-45560-00	GEAR 1 (30T)	1	1			UR *1
62	6P2-45571-00	GEAR 2 (30T)	1	1			UR *1




69J2100-3320

FIG. 33 LOWER CASING & DRIVE 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	6E5-44365-00	DAMPER, WATER SEAL	1	1			
2	6E5-44366-00	DAMPER, WATER SEAL	1	1			
3	69J-44361-00	TUBE, WATER	1	1			X (25.3")
	69J-44361-10	TUBE, WATER	1				U (30.3")
4	93608-12M05	PIN, DOWEL	2	2			
5	97095-10045	BOLT	7	7			X (25.3")
6	92995-10100	WASHER	7	7			X (25.3")
7	92995-10600	WASHER	7	7			X (25.3")
8	90119-10MA2	BOLT, WITH WASHER	1	1			X (25.3")
	90119-10008	BOLT, WITH WASHER	1				U (30.3")
9	69J-45375-00	DAMPER, SEAL	1	1			
10	61A-45214-10	COVER, WATER INLET 1	1	1			
11	61A-45215-10	COVER, WATER INLET 2	1	1			
12	90152-05003	SCREW, COUNTERSUNK	1	1			
13	90185-05002	NUT, SELF-LOCKING	1	1			
14	61A-45371-00	TAB-TRIM	1	1			
15	90105-10M00	BOLT, FLANGE	1	1			
16	69J-45987-00	SPACER	1	1			
17	688-45997-01	SPACER	1	1			
18	92990-18200	WASHER	1	1			
19	90171-18M04	NUT, CASTLE	1	1			
20	91490-40030	PIN, COTTER	1	1			
21	6G5-45970-02-98	PROPELLER (3X15-1/4"X15"-M)	1	1			UR
	6G5-45972-02-98	PROPELLER (3X13-3/4"X21"-M)	1	1			UR
	6G5-45974-03-98	PROPELLER (3X13-3/4"X19"-M2)	1	1			UR
	6G5-45978-03-98	PROPELLER (3X13-3/4"X17"-M2)	1	1			UR
	61A-45972-00-98	PROPELLER (3X14-1/2"X21"-T)	1	1			UR

[illegible]



*1: APPLICABLE SERIAL NO.
60M: 1001065-, 69K: 1007572-

FIG. 34 LOWER CASING & DRIVE 3

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69K-45300-22-8D	LOWER UNIT ASSY			1	1	X (25.3"),LH
	69K-45300-32-8D	LOWER UNIT ASSY			1		U (30.3"),LH
2	61A-45301-10-8D	CASING, LOWER			1	1	
3	93311-832V2	BEARING			1	1	
4	61B-45538-01	SPACER 1			1	1	
5	93315-660W3	BEARING			1	1	
6	93341-670V0	BEARING			1	1	
7	61A-45567-00	SHIM (T:0.10MM)			1	1	UR
	61A-45567-10	SHIM (T:0.12MM)			1	1	UR
	61A-45567-20	SHIM (T:0.15MM)			1	1	UR
	61A-45567-30	SHIM (T:0.18MM)			1	1	UR
	61A-45567-40	SHIM (T:0.30MM)			1	1	UR
	61A-45567-50	SHIM (T:0.40MM)			1	1	UR
	61A-45567-60	SHIM (T:0.50MM)			1	1	UR
8	663-44366-00	DAMPER, WATER SEAL			1	1	
9	90340-08002	PLUG, STRAIGHT SCREW			1	1	
10	688-45341-10	PLUG, DRAIN			1	1	
11	90430-08020	GASKET			2	2	
12	61A-45376-00-94	GUIDE, SEAL DAMPER			1	1	
13	61A-45321-01	PLATE			1	1	
14	93210-64488	O-RING			1	1	
15	93106-09014	OIL SEAL			1	1	
16	90119-06M10	BOLT, WITH WASHER			3	3	
17	69K-44150-00	SHIFT CAM ASSY			1	1	
18	99001-08600	CIRCLIP			1	1	
19	90501-11M10	SPRING, COMPRESSION			1	1	
20	61A-44311-01	HOUSING, WATER PUMP			1	1	





FIG. 34 LOWER CASING & DRIVE 3


REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
21	61A-44322-02	INSERT, CARTRIDGE			1	1	
22	93210-86M38	O-RING			1	1	
23	93210-37160	O-RING			1	1	
24	6E5-44365-00	DAMPER, WATER SEAL			1	1	
25	6E5-44312-00	COVER, WATER PUMP HOUSING			1	1	
26	6E5-44352-01	IMPELLER			1	1	
27	90280-04M05	KEY, WOODRUFF			1	1	
28	61A-45538-00	SPACER 1			1	1	
29	61A-45527-00	COLLAR, DRIVE SHAFT			1	1	
30	90201-22M01	WASHER, PLATE			2	2	
31	90206-22M19	WASHER, WAVE			1	1	
32	6G5-44323-00	OUTER PLATE, CARTRIDGE			1	1	
33	6E5-44315-A0	GASKET, WATER PUMP			1	1	
34	93606-12019	PIN, DOWEL			2	2	
35	90119-08M14	BOLT, WITH WASHER			4	4	
36	61A-45331-00-94	HOUSING, BEARING			1	1	
37	93101-28M16	OIL SEAL			2	2	
38	93317-330U2	BEARING			1	1	
39	61A-45587-00	SHIM (T:0.10MM)			1	1	UR
	61A-45587-10	SHIM (T:0.12MM)			1	1	UR
	61A-45587-20	SHIM (T:0.15MM)			1	1	UR
	61A-45587-30	SHIM (T:0.18MM)			1	1	UR
	61A-45587-40	SHIM (T:0.30MM)			1	1	UR
	61A-45587-50	SHIM (T:0.40MM)			1	1	UR
	61A-45587-60	SHIM (T:0.50MM)			1	1	UR
40	93341-930U9	BEARING			1	1	
41	93210-55M14	O-RING			1	1	



*1: APPLICABLE SERIAL NO.
60M: 1001065-, 69K: 1007572-

FIG. 34 LOWER CASING & DRIVE 3

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
42	6E5-45344-00	COVER, OIL SEAL			1	1	
43	97095-08025	BOLT			4	4	
44	92995-08600	WASHER			4	4	
45	69J-45501-00	DRIVE SHAFT COMP.			1	1	X (25.3")
	61A-45501-30	DRIVE SHAFT COMP.			1		U (30.3")
46	69J-45551-00	PINION (15T)			1	1	UR
47	90201-16M00	WASHER, PLATE			1	1	
48	90170-16M19	NUT			1	1	
49	69K-45560-00	GEAR 1 (30T)			1	1	UR
50	69K-45611-00	SHAFT, PROPELLER			1	1	
51	61B-45641-01	SHIFTER			1	1	
52	61A-45634-01	SLIDE, SHIFT			1	1	
53	61A-45632-00	PIN, CROSS			1	1	
54	69J-45631-00	CLUTCH, DOG			1	1	
55	61A-45633-00	RING, CROSS PIN			1	1	
56	6H1-45668-00	SHAFT, FREE			1	1	
57	61A-45635-00	PLUNGER, SHIFT			2	2	
58	90201-02M00	WASHER, PLATE			1	1	
59	90183-02M03	NUT, SPRING			2	2	
60	90501-10M77	SPRING, COMPRESSION			1	1	
61	93501-04011	BALL			2	2	
62	69K-45332-00-94	HOUSING, BEARING			1	1	
63	93332-00048	BEARING			1	1	
64	69K-45571-00	GEAR 2 (30T)			1	1	UR
65	93341-440U5	BEARING			1	1	
66	6K1-45578-01	SHIM (T:0.10MM)			1	1	UR
	6K1-45578-10	SHIM (T:0.12MM)			1	1	UR




*1: APPLICABLE SERIAL NO.
60M: 1001065-, 69K: 1007572-

FIG. 34 LOWER CASING & DRIVE 3

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
66	6K1-45578-20	SHIM (T:0.15MM)			1	1	UR
	6K1-45578-30	SHIM (T:0.18MM)			1	1	UR
	6K1-45578-40	SHIM (T:0.30MM)			1	1	UR
	6K1-45578-50	SHIM (T:0.40MM)			1	1	UR
	6K1-45578-60	SHIM (T:0.50MM)			1	1	UR
67	61B-45383-00	WASHER, CLAW			1	1	
68	69K-45384-00	NUT			1	1	
69	69K-45577-00	SHIM (T:0.10MM)			1	1	UR
	69K-45577-10	SHIM (T:0.12MM)			1	1	UR
	69K-45577-20	SHIM (T:0.15MM)			1	1	UR
69K-45577-30		SHIM (T:0.18MM)			1	1	UR
	69K-45577-40	SHIM (T:0.30MM)			1	1	UR
	69K-45577-50	SHIM (T:0.40MM)			1	1	UR
	69K-45577-60	SHIM (T:0.50MM)			1	1	UR
70	93315-43061	BEARING			1	1	
71	93101-30M17	OIL SEAL			2	2	
72	93211-04384	O-RING			2	2	
73	90105-08036	BOLT, FLANGE			2	2	
74	90201-08023	WASHER, PLATE			2	2	
75	93700-09M00	NIPPLE, GREASE			1	1	
76	69J-45361-00-8D	CAP, LOWER CASING			1	1	
77	97095-08020	BOLT			2	2	
78	92995-08600	WASHER			2	2	
46	6P2-45551-01	PINION (15T)			1	1	UR *1
49	6P3-45560-00	GEAR 1 (30T)			1	1	UR *1
64	6P3-45571-00	GEAR 2 (30T)			1	1	UR *1



COUNTER ROTATION



69K2100-3340

FIG. 35 LOWER CASING & DRIVE 4

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	6E5-44365-00	DAMPER, WATER SEAL			1	1	
2	6E5-44366-00	DAMPER, WATER SEAL			1	1	
3	69J-44361-00	TUBE, WATER			1	1	X (25.3")
	69J-44361-10	TUBE, WATER			1		U (30.3")
4	93608-12M05	PIN, DOWEL			2	2	
5	97095-10045	BOLT			7	7	X (25.3")
6	92995-10100	WASHER			7	7	X (25.3")
7	92995-10600	WASHER			7	7	X (25.3")
8	90119-10MA2	BOLT, WITH WASHER			1	1	X (25.3")
	90119-10008	BOLT, WITH WASHER			1		U (30.3")
9	69J-45375-00	DAMPER, SEAL			1	1	
10	61A-45214-10	COVER, WATER INLET 1			1	1	
11	61A-45215-10	COVER, WATER INLET 2			1	1	
12	90152-05003	SCREW, COUNTERSUNK			1	1	
13	90185-05002	NUT, SELF-LOCKING			1	1	
14	61A-45371-00	TAB-TRIM			1	1	
15	90105-10M00	BOLT, FLANGE			1	1	
16	69J-45987-00	SPACER			1	1	
17	688-45997-01	SPACER			1	1	
18	92990-18200	WASHER			1	1	
19	90171-18M04	NUT, CASTLE			1	1	
20	91490-40030	PIN, COTTER			1	1	
21	6K1-45970-01-98	PROPELLER (3X15-1/4"X15"-ML)			1	1	UR
	6K1-45972-01-98	PROPELLER (3X13-3/4"X21"-ML)			1	1	UR
	6K1-45974-02-98	PROPELLER (3X13-3/4"X19"-ML1)			1	1	UR
	6K1-45978-02-98	PROPELLER (3X13-3/4"X17"-ML1)			1	1	UR
	61B-45972-00-98	PROPELLER (3X14-1/2"X21"-TL)			1	1	UR



60V2100-C330

FIG. 36 STEERING GUIDE

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	6E5-61350-02	STEERING GUIDE ATTACHMENT KIT	1	1			AP
2	6E5-61351-01	.ROD, STEERING LINK	1	1			
3	90387-10M61	.COLLAR	1	1			
4	90560-12M01	.SPACER	1	1			
5	6E5-61355-00	.BOLT	1	1			
6	90185-09M01	.NUT, SELF-LOCKING	2	2			
7	90201-10M20	.WASHER, PLATE	2	2			
8	6E5-43145-01	.CAP, CLAMP BRACKET	1	1			
9	93210-16275	.O-RING	1	1			
10	6E5-61301-01	TWIN KIT (L:600-800MM)			1	1	AP
11	6E5-61313-00	.ADJUSTER			1	1	
12	6E5-61311-11	.TIE BAR			1	1	
13	6E5-61315-00	.TIE BAR			1	1	
14	6E5-61303-00	.STEERING EYE COMP.			2	2	
15	90170-14M06	.NUT			1	1	
16	95380-14700	.NUT			2	2	
17	90201-10M76	.WASHER, PLATE			2	2	
18	90101-09M70	.BOLT			2	2	
19	90170-09M05	.NUT			2	2	
20	90185-09M01	.NUT, SELF-LOCKING			2	2	




FIG. 38 METER

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	6Y5-8350T-03	DIGITAL TACHOMETER ASSY	1	1	1	1	AP FOR OCE,CAR
2	9E450-04433	.CONNECTOR	1	1	1	1	M-4-W
3	9E450-04533	.CONNECTOR	1	1	1	1	F-4-W
4	92990-04100	.WASHER, SPRING	2	2	2	2	
5	95380-04600	.NUT	2	2	2	2	
6	6Y5-83500-S5	DIGITAL SPEEDOMETER ASSY	1	1			AP FOR OCE,CAR
7	6Y5-83570-S5	.SPEEDOMETER ASSY	1	1			
8	92990-04100	..WASHER, SPRING	2	2			
9	95380-04600	..NUT	2	2			
10	6Y5-83533-T2	..GROMMET	1	1			
11	6Y5-83557-31	.TUBE	1	1			
12	6Y5-83728-00	.CONNECTOR ASSY	1	1			
13	90465-11M10	.CLAMP	2	2			
14	6Y5-87122-S0	CORD ASSY 1	1	1			AP FOR OCE,CAR
15	6Y5-83553-M0	WIRE, LEAD (L=2.5M)	1	1			AP FOR OCE,CAR
	6Y5-83553-00	WIRE, LEAD (L=2.5M)			1	1	AP FOR OCE,CAR
16	1E6-82151-00	.FUSE (10A)	2	2			FOR 6Y5-83553-M0
	1E6-82151-00	.FUSE (10A)			1	1	FOR 6Y5-83553-00
17	6Y5-82117-00	WIRE, LEAD (BLACK)	1	1			AP FOR OCE,CAR
18	68F-82553-80	EXTENSION, WIRE LEAD (L=8.0M)	1	1			AP FOR OCE,CAR
	68F-82553-90	EXTENSION, WIRE LEAD (L=9.5M)			1	1	AP FOR OCE,CAR
19	6Y5-83557-10	TUBE (8M)	1	1			AP FOR OCE,CAR
20	90465-11M10	CLAMP	2	2			AP FOR OCE,CAR
21	6Y5-8350F-00	FUEL MANAGEMENT METER			1	1	AP FOR OCE,CAR
22	6Y5-87122-S0	.CORD ASSY 1			1	1	
23	6Y5-83553-F1	WIRE, LEAD (L=8.0M)			1	1	AP FOR OCE,CAR
24	6Y5-85752-01	SENDER UNIT ASSY, FUEL METER			2	2	AP FOR OCE,CAR




FIG. 38 METER




FIG. 39 SWITCH & PANEL 1

REF. NO.	PART NO.	DESCRIPTION	68J5	60L5	69K5	60M5	REMARKS
1	6K1-82570-08	PANEL SWITCH ASSY			1	1	AP FOR OCE
2	6K1-82571-02	.PANEL, SWITCH			1	1	
3	6K1-82510-06	.MAIN SWITCH ASSY			2	2	
4	703-82577-00	..CAP, KEY			1	1	
5	6K1-82532-00	..CAP			1	1	
6	6K1-82575-00	..ENGINE STOP SWITCH ASSY			1	1	
7	682-82556-00	..STOPPER			1	1	
8	6K1-83614-01	.BRACKET			1	1	
9	98980-05010	.SCREW, BIND			2	2	
10	92990-05100	.WASHER, SPRING			2	2	
11	95380-05600	.NUT			2	2	
12	688-83383-11	.BUZZER			2	2	
13	6K1-85830-01	.CONTROL UNIT ASSY			1	1	
14	98980-06020	.SCREW, BIND			2	2	
15	95380-06600	.NUT, HEXAGON			2	2	
16	92990-06100	.WASHER, SPRING			2	2	
17	92990-06600	.WASHER, PLATE			2	2	
18	6K1-81980-00	.DIODE ASSY			2	2	
19	90149-05M05	SCREW			4	4	AP FOR OCE
20	95380-05600	NUT			4	4	AP FOR OCE
21	92990-05100	WASHER, SPRING			4	4	AP FOR OCE
22	92990-05600	WASHER, PLATE			4	4	AP FOR OCE
23	6K1-8258A-40	EXTENSION, WIRE HARNESS (8M)			1	1	AP FOR OCE (10P)
24	61B-8258A-01	EXTENSION, WIRE HARNESS (9.5M)			1	1	AP FOR OCE (10P)





FIG. 40 SWITCH & PANEL 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	6R5-82570-05	PANEL SWITCH ASSY	1	1			AP FOR CAR
2	6R5-82588-01	.PLATE	1	1			
3	704-82571-02	.PANEL, SWITCH	1	1			
4	6R5-82510-02	.MAIN SWITCH ASSY	1	1			
5	676-82577-00	..CAP, KEY	1	1			
6	688-82575-01	.ENGINE STOP SWITCH ASSY	1	1			
7	682-82556-00	..STOPPER	1	1			
8	64D-82581-00	.STAY, CORD CLAMP	1	1			
9	97303-05012	.BOLT	1	1			
10	92903-05100	.WASHER, SPRING	1	1			
11	95303-05700	.NUT	1	1			
12	6R5-83383-00	.BUZZER	1	1			
13	90149-05M05	SCREW	4	4			AP FOR CAR
14	95303-05600	NUT	4	4			AP FOR CAR
15	92903-05100	WASHER, SPRING	4	4			AP FOR CAR
16	92903-05600	WASHER, PLATE	4	4			AP FOR CAR
17	6K1-8258A-40	EXTENSION, WIRE HARNESS (8M)	1	1			AP FOR CAR (10P)



67H1100-2360

FIG. 41 SWITCH & PANEL 3

REF. NO.	PART NO.	DESCRIPTION	68J5	60L5	69K5	60M5	REMARKS
1	61B-82570-03	PANEL SWITCH ASSY			1	1	AP FOR CAR
2	61B-82588-01	.PLATE			1	1	
3	6K1-82571-02	.PANEL, SWITCH			1	1	
4	61B-82510-01	.MAIN SWITCH ASSY			2	2	
5	676-82577-00	..CAP, KEY			1	1	
6	6K1-82575-00	..ENGINE STOP SWITCH ASSY			1	1	
7	682-82556-00	..STOPPER			1	1	
8	6K1-83614-01	.BRACKET			1	1	
9	98980-05010	.SCREW, BIND			2	2	
10	92990-05100	.WASHER, SPRING			2	2	
11	95380-05600	.NUT			2	2	
12	6R5-83383-00	.BUZZER			2	2	
13	61B-85830-00	.CONTROL UNIT ASSY			1	1	
14	98980-06020	.SCREW, BIND			2	2	
15	95380-06600	.NUT, HEXAGON			2	2	
16	92990-06100	.WASHER, SPRING			2	2	
17	92990-06600	.WASHER, PLATE			2	2	
18	6K1-8258A-40	EXTENSION, WIRE HARNESS (8M)			1	1	AP FOR CAR (10P)
19	61B-8258A-01	EXTENSION, WIRE HARNESS (9.5M)			1	1	AP FOR CAR (10P)
20	90149-05M05	SCREW			4	4	AP FOR CAR
21	95380-05600	NUT			4	4	AP FOR CAR
22	92990-05600	WASHER, PLATE			4	4	AP FOR CAR
23	92990-05100	WASHER, SPRING			4	4	AP FOR CAR




FIG. 42 REPAIR KIT 1

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-W0001-04	POWER HEAD GASKET KIT	1	1	1	1	
2	69J-15451-00	.GASKET, CRANKCASE COVER 1	1	1	1	1	
3	6S1-1131B-00	.GASKET, COVER	1	1	1	1	
4	69J-11351-11	.GASKET, CYLINDER	1	1	1	1	
5	93210-25552	.O-RING	3	3	3	3	
6	93210-19MJ1	.O-RING	2	2	2	2	
7	93210-25647	.O-RING	1	1	1	1	
8	69J-13477-00	.GASKET	1	1	1	1	
9	93210-24M79	.O-RING	1	1	1	1	
10	69J-15364-A0	.GASKET, OIL PLUG	1	1	1	1	
11	93102-63004	.OIL SEAL	1	1	1	1	
12	69J-11181-03	.GASKET, CYLINDER HEAD 1	1	1	1	1	
13	69J-11182-03	.GASKET, CYLINDER HEAD 2	1	1	1	1	
14	69J-11193-01	.GASKET, HEAD COVER 1	1	1	1	1	
15	69J-11194-00	.GASKET, HEAD COVER 2	1	1	1	1	
16	6P2-41112-00	.GASKET, EXHAUST INNER COVER	1	1	1	1	
17	6P2-41114-00	.GASKET, EXHAUST OUTER COVER	2	2	2	2	
18	90430-08143	.GASKET	4	4	4	4	
19	90430-18130	.GASKET	2	2	2	2	
20	93102-38M59	.OIL SEAL	2	2	2	2	
21	69J-13557-00	.GASKET	6	6	6	6	
22	69J-13645-00	.GASKET, MANIFOLD 1	2	2	2	2	
23	69J-13338-00	.OIL SEAL	1	1	1	1	
24	69J-11355-00	.SEAL, CYLINDER 1	1	1	1	1	
25	93210-19MJ3	.O-RING	1	1	1	1	
26	69J-14664-00	.GROMMET, WATER SHUT	2	2	2	2	
27	6P2-41122-00	.GASKET, EXHAUST INNER COVER	1	1	1	1	




FIG. 43 REPAIR KIT 2

REF. NO.	PART NO.	DESCRIPTION	69J5	60L5	69K5	60M5	REMARKS
1	69J-W0001-22	LOWER UNIT GASKET KIT	1	1	1	1	
2	93210-28543	.O-RING	1	1	1	1	
3	93210-33MG4	.O-RING	1	1	1	1	
4	6P2-41134-00	.GASKET, EXHAUST MANIFOLD	1	1	1	1	
5	69J-41138-00	.SEAL, EXT. 1	1	1	1	1	
6	69J-41135-A0	.GASKET, EXHAUST MANIFOLD	1	1	1	1	
7	6S1-41136-00	.GASKET, EXHAUST MANIFOLD 4	1	1	1	1	
8	69J-45127-00	.SEAL	1	1	1	1	
9	69J-45123-00	.GASKET, MUFFLER	1	1	1	1	
10	69J-45113-20	.GASKET, UPPER CASING	1	1	1	1	
11	69J-15312-01	.GASKET, OIL PAN	1	1	1	1	
12	90430-14M09	.GASKET	1	1	1	1	
13	69J-13415-00	.SEAL, OIL STRAINER	1	1	1	1	
14	90430-08020	.GASKET	2	2	2	2	
15	93210-64488	.O-RING	1	1	1	1	
16	93106-09014	.OIL SEAL	1	1	1	1	
17	93210-86M38	.O-RING	1	1	1	1	
18	93210-37160	.O-RING	1	1	1	1	
19	6E5-44365-00	.DAMPER, WATER SEAL	1	1	1	1	
20	6E5-44315-A0	.GASKET, WATER PUMP	1	1	1	1	
21	93101-28M16	.OIL SEAL	2	2	2	2	
22	93210-55M14	.O-RING	1	1	1	1	
23	93101-30M17	.OIL SEAL	2	2	2	2	
24	93211-04384	.O-RING	2	2	2	2	
25	6E5-44366-00	.DAMPER, WATER SEAL	1	1	1	1	
26	61A-W0078-A3	WATER PUMP REPAIR KIT	1	1	1	1	
27	61A-44322-02	.INSERT, CARTRIDGE	1	1	1	1	

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
90465-08M83	26 - 18	91814-18001	2 - 4	92995-08600	18 - 8	93210-37160	32 - 21	93608-12M05	30 - 55	97095-06016	14 - 16
90465-11M10	2 - 40	92903-05100	40 - 10		30 - 26		34 - 23		33 - 4		16 - 18
	8 - 23	92903-05600	40 - 16		31 - 5		43 - 18		35 - 4		18 - 2
	14 - 4	92903-06600	18 - 28		32 - 42	93210-55M14	32 - 39	93608-16M16	30 - 6	97095-06020	2 - 50
	21 - 18	92903-08100	20 - 30		34 - 44		34 - 41		31 - 6		17 - 5
	22 - 18	92903-08600	20 - 28	92995-10100	33 - 6		43 - 22	93700-06M01	23 - 9		18 - 4
	23 - 18	92907-04600	2 - 17		35 - 6	93210-64488	32 - 12	93700-06M03	26 - 17		19 - 5
	26 - 25		4 - 34	92995-10600	30 - 4		34 - 14	93700-09M00	32 - 70		21 - 39
	30 - 44	92907-06600	31 - 13		33 - 7		43 - 15		34 - 75		24 - 24
	38 - 13	92990-04100	38 - 4		35 - 7	93210-86M38	32 - 20	94581-99044	6 - 13		30 - 13
90465-11M52	7 - 21	92990-05100	39 - 10	92995-14600	27 - 21		34 - 22	94702-00391	4 - 42		31 - 25
90465-13M30	21 - 9		41 - 10	93101-28M16	32 - 35		43 - 17	95303-05600	40 - 14	97095-06025	2 - 36
90465-14M66	7 - 5	92990-05600	39 - 22		34 - 37	93211-04384	32 - 67	95303-05700	40 - 11		26 - 4
	16 - 20		41 - 22		43 - 21		34 - 72	95333-08600	20 - 29	97095-06030	4 - 36
	18 - 32	92990-06100	1 - 7	93101-30M17	32 - 66		43 - 24	95380-04600	38 - 5	97095-06035	16 - 7
	19 - 4		39 - 16		34 - 71	93306-210U0	32 - 61	95380-05600	25 - 3		19 - 8
90467-08M18	17 - 23		41 - 16		43 - 23	93311-832V2	32 - 3		39 - 11		23 - 6
90467-09M03	7 - 10	92990-06600	30 - 51	93102-38M59	6 - 20		34 - 3		41 - 11	97095-06040	2 - 60
	17 - 22		39 - 17		42 - 20	93315-43061	32 - 65	95380-06600	1 - 8	97095-06045	2 - 57
90468-18008	23 - 4		41 - 17	93102-63004	3 - 2		34 - 70		39 - 15		24 - 16
	24 - 14	92990-08100	9 - 4		42 - 11	93315-660W3	34 - 5		41 - 15	97095-08014	5 - 15
90480-06M19	15 - 4		10 - 4	93106-09014	32 - 13	93317-330U2	32 - 36	95380-10600	30 - 60	97095-08020	18 - 7
90480-09M21	17 - 2	92990-10100	30 - 59		34 - 15		34 - 38	95380-12600	26 - 51		32 - 72
90480-10M23	8 - 6	92990-10600	17 - 28		43 - 16	93332-00048	34 - 63	95380-14700	36 - 16		34 - 77
90480-14M17	22 - 6		30 - 58	93106-19N50	28 - 5	93332-000W1	32 - 4	95680-05100	25 - 10	97095-08025	32 - 41
90480-22M81	21 - 15	92990-18200	33 - 18	93210-064A5	28 - 51	93341-440U5	34 - 65	95707-06500	2 - 9		34 - 43
90501-10M77	32 - 58		35 - 18	93210-08391	28 - 48	93341-670V0	34 - 6	95780-10300	27 - 5	97095-08035	31 - 4
	34 - 60	92995-04100	23 - 17	93210-09165	23 - 34	93341-930U9	32 - 38	97013-06025	6 - 16	97095-10045	33 - 5
90501-11M10	32 - 17	92995-06100	14 - 17		29 - 18		34 - 40		18 - 27		35 - 5
	34 - 19		16 - 8	93210-16275	36 - 9	93399-999T6	29 - 3	97013-08045	20 - 27	97303-05012	40 - 9
90501-12082	23 - 29		17 - 18	93210-17239	28 - 22	93410-10082	24 - 5	97027-06025	31 - 12	97575-06540	31 - 20
90506-16003	26 - 42		18 - 18	93210-18397	28 - 27	93410-18M02	26 - 46	97075-06020	4 - 17	97575-08540	4 - 20
90506-16M34	21 - 51		19 - 6	93210-19MJ1	2 - 47	93410-37M04	27 - 12	97075-06030	23 - 30	97575-08560	31 - 3
90508-20020	23 - 12		31 - 26		42 - 6	93420-36M01	30 - 39	97075-08035	30 - 25	97575-08590	30 - 19
90560-12M01	36 - 4	92995-06600	1 - 11	93210-19MJ3	31 - 24	93501-04011	32 - 59	97075-10045	30 - 3	97575-10535	30 - 5
91318-05025	28 - 60		2 - 37		42 - 25		34 - 61	97095-06010	9 - 26	97780-60520	22 - 19
91318-05040	28 - 65		4 - 18	93210-24M79	2 - 63	93501-04M02	23 - 28		10 - 21	97780-60620	7 - 8
91490-20015	23 - 37		8 - 11		42 - 9	93501-08001	28 - 47		18 - 17		18 - 21
91490-40030	33 - 20		14 - 15	93210-25552	2 - 46	93503-16003	28 - 37		26 - 7	97780-60625	18 - 34
	35 - 20		16 - 9		31 - 21	93505-32038	28 - 13		30 - 41	97880-06016	30 - 50
91690-30008	25 - 6		17 - 6		42 - 5	93604-35236	28 - 61	97095-06012	17 - 25	97885-04016	23 - 16
91690-30010	23 - 32		18 - 3	93210-25647	2 - 49	93605-10108	6 - 17	97095-06014	14 - 14	97885-06010	16 - 15
91690-30018	24 - 8		19 - 7		42 - 7	93606-12019	2 - 3		18 - 9		21 - 6
91690-30020	26 - 41		23 - 7	93210-28543	30 - 9		30 - 47		24 - 19		26 - 13
91690-30025	24 - 7		24 - 17		43 - 2		32 - 32		26 - 27	97885-06012	26 - 10
91690-40010	5 - 12		26 - 5	93210-33MG4	30 - 10		34 - 34		30 - 37	97885-06016	27 - 3
91690-50014	7 - 13		30 - 14		43 - 3		43 - 33	97095-06016	1 - 10	98507-04008	2 - 16
91809-08006	4 - 5		31 - 27	93210-35321	27 - 9	93606-19M23	30 - 27		8 - 10		4 - 33

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
98507-04008	12 – 14								
98582-05008	13 – 22								
98780-04015	2 – 73								
	5 – 10								
98980-05010	39 – 9								
	41 – 9								
98980-06020	39 – 14								
	41 – 14								
99001-03600	28 – 40								
99001-08600	32 – 16								
	34 – 18								
99530-08012	16 – 6								
99530-10114	9 – 29								
	10 – 24								
9E450-04433	38 – 2								
9E450-04533	38 – 3								

F200/F225/LF200/LF225
F200A/F225A/FL200A/FL225A
PARTS CATALOGUE
©2005 by Yamaha Motor Co., Ltd.
1st edition, March 2005
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.